

RESTRICTED

AN 01-5MC-1

PRELIMINARY
Pilot's Handbook
of
Flight Operating Instructions

NAVY MODEL
PBY-6A Airplane

THIS PUBLICATION SUPERCEDES AN 01-5MC-1
DATED 1 DECEMBER 1944

Appendix I of this publication shall not be carried on aircraft on combat missions or where there is a reasonable chance of its falling into the hands of the enemy

NOTICE.—This document contains information affecting the national defense of the United States within the meaning of the Espionage Act, 50 U. S. C., 31 and 32, as amended. Its transmission or the revelation of its contents in any manner to an unauthorized person is prohibited by law.

TABLE OF CONTENTS


SECTION	PAGE	SECTION	PAGE
I DESCRIPTION			
1. Airplane-Description and General Arrangement	1	19. Approach and Landing	44
2. Locations and Arrangement of Flight Controls	1	20. Stopping Engines	46
3. Arrangement of Miscellaneous Controls	7	21. Before Leaving the Pilot's Compartment	47
4. Instruments	13	III FLIGHT OPERATING DATA	
5. Gunfire Protection for Personnel and Equipment	15	1. Engine Performance Ratings	49
6. Movement of Flight Personnel	15	2. Air Speed Limitations	49
II PILOT'S OPERATING INSTRUCTIONS		3. Air Speed Calibration Chart	50
1. Before Entering the Pilot's Compartment	25	4. Balance Computer Designation	50
2. On Entering the Pilot's Compartment	26	IV EMERGENCY OPERATING INSTRUCTIONS	
3. Fuel System Management	28	1. Emergency Operation of Landing Gear	51
4. Starting Engines	34	2. Emergency Operation of Floats	51
5. Engine Warm-up and Accessory Check	36	3. Emergency Take-off	54
6. Emergency Take-off	38	4. Engine Failure During Take-off	54
7. Engine and Accessories Operation Ground Test	38	5. Engine Failure During Landing	55
8. Taxiing Instructions	38	6. Miscellaneous Emergency Measures	55
9. Take-off	38	V OPERATIONAL EQUIPMENT	
10. Engine Failure During Take-off	41	1. Remote Compartments	59
11. Climb and High Speed Level Flight	41	2. Operation of Oxygen Equipment	59
12. General Flying Characteristics	42	3. Operation of Communication Equipment	61
13. Maneuvers Prohibited	42	4. Armament	80
14. Stalls	42	5. Operation of Central Heater	88
15. Spins	43	6. Operation of Propeller, Wing and Tail Anti-Icing System	89
16. Acrobatics	43	7. Operation of Auxiliary Power Unit	89
17. Diving	43	APPENDIX I	
18. Night Flying	44	Flight Operating Charts, Tables, Curves and Diagrams	91



Three-Quarters Rear View



Three-Quarters Front View



SECTION I DESCRIPTION

I. AIRPLANE—DESCRIPTION AND GENERAL ARRANGEMENT.

This airplane is an all metal, two engine amphibian, with a flying boat hull 62 ft. 10 $\frac{3}{8}$ in. long, equipped with retractable tricycle type landing gear. It is powered by two Pratt and Whitney R-1830-92 engines.

Wing span is 104 ft. The wing is mounted on a superstructure built up from the hull, and is braced by four struts, two on each side, extending from the hull to the under surface of the wing. Wing main center and outer panels are aluminum alloy, beam and truss, stressed skin construction, with detachable trailing edges made of braced aluminum alloy ribs covered with doped fabric. Leading edges of both center and outer panel are all metal, and are detachable. Main panel and leading and trailing edge structures incorporate ducts for the heat anti-icing system, which derives its heat from the engine exhaust. The wing also incorporates the engine nacelles, fuel and oil tanks and the two retractable auxiliary floats and their operating mechanism.

The two ailerons and their trailing edge fairings are constructed of braced metal ribs, fabric covered. The port aileron has a metal trim tab which may be adjusted by the pilot during flight.

The tail group consists of a stabilizer, elevators with controllable tabs, a fin, and a rudder with a controllable tab. The stabilizer and upper fin assembly is bolted to the lower fin, which is the aft portion of the hull. The stabilizer is all metal. Rudder and elevators are metal frames, fabric covered. The trim tabs are of metal construction and may be adjusted by the pilot during flight.

The hull is divided into five main watertight compartments, separated by four main bulkheads equipped with watertight doors. The bomber's compartment is in the nose of the hull. Immediately aft of the bomber's compartment is the pilot's compartment which extends aft as far as the first watertight bulkhead.

Radio operator's and navigator's compartment is aft of the pilot's compartment. Radio and radar operators

occupy the starboard side of the compartment. The navigator is stationed on the port side of the same compartment. The engineer's station is in the superstructure which supports the wing. The compartment immediately below the engineer's station contains the galley stove and food locker. This compartment is narrow because of the indentations of the landing wheel wells. The crew quarters are aft of the galley compartment and contains the auxiliary power unit. The gun blisters and tail compartment are aft of the crew's quarters.

2. LOCATIONS AND ARRANGEMENT OF FLIGHT CONTROLS.

a. BOMBER'S COMPARTMENT.—There are no flight controls located in the bomber's compartment.

b. PILOT'S COMPARTMENT.


(See figure 1.)

(1) SURFACE CONTROLS. (See figures 15 to 19 incl.)—Dual surface controls are provided for pilot and copilot. Rudder control is in the form of two sets of pedals. Elevator control is in the form of a movable yoke. This yoke consists of two vertical supports on either side of the cockpit, and a horizontal bar parallel to the instrument panel, joining the tops of the two vertical members. Elevator control is achieved by moving the yoke forward or aft in the conventional control stick movements.

Aileron controls, consisting of two hand wheels mounted on the horizontal yoke bar at the pilot's and copilot's positions, are linked together by a chain and cable loop which runs over a sprocket on each wheel shaft. The hand wheels turn 267° each side of neutral.

The aileron tab is controlled by a hand wheel located on the pilot's instrument panel beam. This wheel turns in either direction; movement of the tab is indicated on a dial.

The rudder and elevator tab controls are in one housing located overhead in the ceiling of the pilot's compartment. The knob at the bottom is for the rudder



RADIO COMPASS
CONTROL BOX

FAST FEATHERING SWITCHES

THROTTLE & PROP
QUADRANT

FWD

Figure 1—General View of Pilot's Compartment

tab, and is operated by turning the knob in the direction trim correction is required. The elevator tab control cranks are accessible to both pilot and copilot and act as dual controls. These cranks may be moved clockwise or counterclockwise; a dial on the face of the housing indicates movement of the tabs.

(2) LANDING GEAR AND BRAKE CONTROLS.

(See figure 4.)

(a) DESCRIPTION.

1. LANDING GEAR CONTROLS.—Operating control for the hydraulic landing gear lowering and retracting mechanism is a selector valve handle and lock located at the bottom of the main instrument panel on the pilot's side.

2. BRAKE CONTROLS.—Pedals to operate the landing wheel brakes are mounted on the top of the rudder pedals.

3. PARKING BRAKE.—(See Section II, paragraph 21.)

(b) LANDING GEAR OPERATION.

1. TO LOWER GEAR:

a. Turn control handle to "DOWN" position. Be sure that lever safety catch clicks into place, locking handle in "DOWN" position.

b. Turn indicator light switch on instrument panel to "W" position. Landing gear down light will show when main and nose wheels are all down and latched. If manifold pressure is decreased below 15 inches Hg, the float warning lights on both engineer's and pilot's panel will show red, indicating that the floats are up.

2. TO RAISE GEAR:

a. Pull lock knob on landing gear control handle to release handle.

b. Turn handle to "UP" position.

Note

The two lights indicating "MAIN LANDING GEAR UP" and "NOSE WHEEL DOOR LOCKED" will not show until the main wheels are both securely latched and the nose wheel doors are closed and latched.

CAUTION

Gear control lever must be either all the way up or all the way down at all times; do not allow it to remain in any intermediate position.

(3) POWER PLANT CONTROLS.

(See figure 1.)

(a) THROTTLE CONTROL.—The throttle control levers are located on the ceiling of the pilot's compartment approximately at the center of the airplane.

(b) PROPELLER CONTROL.—The propeller governor control levers are located alongside and to the right of the throttle control levers, propeller feathering switches, ahead of the propeller governor levers. All other power plant controls are in the engineer's compartment.

(4) AUTOMATIC PILOT CONTROLS. (See figures 2 and 3.)—The Sperry Mark 3 automatic pilot is in the center cut-out of the main instrument panel. The main four way oil valve for the system is on the port side of the hull, just forward of the pilot's seat. The servo speed control valves are at the bottom of the automatic pilot panel. The "ON-OFF" control handle is over the bulkhead door just aft of the pilot's seat. The rudder control transfer valve is located on the port side, below the pilot's instrument panel.






Figure 3—Auto-Pilot Control

(5) ELECTRICAL CONTROLS.—The ignition switch is located on the pilot's control yoke, on the port side of the pilot's visual indicator, just below the pilot's signal panel. (See figure 8.)

The Fast Feathering switches are located just forward of the throttle controls. (See figure 1.)



- 1 SUCTION GAGE
- 2 AIRSPEED INDICATOR
- 3 GYRO HORIZON INDICATOR
- 4 RATE OF CLIMB INDICATOR
- 5 RADIO COMPASS
- 6 ALTIMETER
- 7 DIRECTIONAL GYRO
- 8 TURN AND BANK INDICATOR
- 9 VACUUM SELECTOR VALVE
- 10 RADIO ALTIMETER
- 11 REMOTE INDICATING COMPASS
- 12 PILOT'S DIRECTION INDICATOR
- 13 RUDDER CONTROL TRANSFER VALVE
- 14 SUCTION GAGE
- 15 ALLERON TAB CONTROL
- 16 DUAL TACHOMETER AND SYNCHRONIZER
- 17 MARKER BEACON LIGHT
- 18 L ENG MANIFOLD PRESSURE GAGE
- 19 R ENG MANIFOLD PRESSURE GAGE
- 20 FLOAT WARNING LIGHT
- 21 GYROPILOT DIRECTIONAL GYRO
- 22 RUDDER CONTROL KNOB
- 23 ALLERON CONTROL KNOB
- 24 CLIMB AND BANK INDICATOR
- 25 ELEVATOR CONTROL KNOB
- 26 GYROPILOT SUCTION GAGE
- 27 SUCTION GAGE
- 28 GYRO RUDDER SPEED CONTROL VALVE
- 29 GYRO ALLERON SPEED CONTROL VALVE
- 30 GYRO ELEVATOR SPEED CONTROL VALVE
- 31 GYROPILOT OIL PRESSURE GAGE
- 32 RADIO ALTIMETER LIGHTS
- 33 CLOCK
- 34 RADIO ALTIMETER SELECTOR SWITCH
- 35 HYDRAULIC PRESSURE GAGE
- 36 LANDING GEAR WARNING LIGHT SWITCH
- 37 LANDING GEAR WARNING LIGHTS
- 38 EMERGENCY BOMB RELEASE
- 39 LANDING GEAR SELECTOR VALVE

Figure 4—Pilot's Instrument Panel




Figure 5—Main Distribution Panel

The landing gear warning lights and switch are located on the extreme starboard side of the pilot's instrument panel.

c. RADIO OPERATOR-NAVIGATOR'S COMPARTMENT.—The main distribution panel is located over the radio operator's table on the forward face of bulkhead 4.

The flight controls located on this panel are the main generator and auxiliary generator switches, battery ammeters, the voltmeter and voltmeter selector switch, and the main battery switch. (See figure 5.)

d. ENGINEER'S COMPARTMENT.

(1) POWER PLANT CONTROLS.

(See figures 7 and 21.)

(a) MIXTURE CONTROL.—The carburetor mixture control levers and quadrant are located above the center of the engineer's instrument panel between the fuel flowmeters.

(b) CARBURETOR AIR CONTROL.—The alternate carburetor air intake control handles are on the engineer's instrument panel on either side of the electrical switch panel.

(c) COWL FLAP CONTROLS.—The cowl flap hand cranks are below the instrument panel bulkhead.

(2) FLOAT CONTROLS—NORMAL OPERATION.

(a) TO LOWER FLOATS:

1. Turn float switch on instrument panel to "FLOATS DOWN" position.

2. If throttles are retarded to 15 inches manifold pressure, the float warning lights on pilot's and engineer's instrument panels will go on until floats are down and latched.

3. Do not begin to lower floats at a speed greater than 130 knots.

(b) TO RAISE FLOATS: Turn float switch on instrument panel to "FLOATS UP."

(3) FUEL SYSTEM CONTROLS.

(a) EMERGENCY FUEL PUMP (wobble pump) handles are at the top center of the engineer's instrument panel, above the electrical switch panel and below the fuel flowmeters.

(b) ENGINE PRIMER is immediately below the port window of the engineer's compartment.

(c) FUEL TANK SELECTOR VALVES are on either side of the instrument panel, under the carburetor air control handles.

(d) THE FUEL CROSS-FEED VALVE, used only in case of a fuel pump failure, is at the lower left corner of the instrument panel.

(e) THE FUEL STRAINER DRAIN VALVES are on either side of the instrument panel, the left-hand drain valve being immediately above the cross-feed valve, and the right-hand valve in the bottom right-hand corner of the instrument panel.

(f) FUEL TANK DRAIN VALVES are on either side of the upper part of the engineer's compartment, aft of the engineer's seat.

(g) FUEL SIGHT GAGE SHUT-OFF VALVES are in the castings on the lower surface of the wing of all sight gages.

(h) FUEL DUMP VALVE CONTROL is in the top of the engineer's compartment, directly above his seat.

(i) FUEL TANK CO₂ PURGING SYSTEM HANDLE is just aft of the starboard window, at the rear of the engineer's seat.

(j) BYPASS CONTROL HANDLES for the fuel flowmeters are on the bottoms of the flowmeters.

(k) A diagram of the airplane fuel system, indicating how the fuel valves should be operated, is mounted on a card just ahead of the port window.

(4) OIL SYSTEM CONTROLS.—Oil dilution control switches are on the electrical switch panel. Oil gage energizer and selector switches are on the same panel, to the left of the oil dilution switches.

(5) ELECTRICAL CONTROLS.—The electrical flight controls, located near the top of the instrument panel, consist of the port and starboard engines starter switches.

The float switch is described in Section I, paragraph 2, d, (2)

(6) AUXILIARY POWER PLANT CONTROLS.—The auxiliary power plant fuel valve is on the right-hand side of the instrument panel, just above the starboard strainer drain valve.

e. CREW'S QUARTERS—AUXILIARY POWER PLANT CONTROLS. (See figure 6.)—The Lawrence type 1A, Model 30D auxiliary power plant is situated on the port side of the crew's quarters, just above the bunk. The unit is started manually by means of a rope wrapped around the starting pulley.

In an emergency, the thermostat override control, which is mounted on the left side of the engine, below and aft of the starting pulley, can be used to immediately advance the engine rpm to operating range.

On the right-hand side of the carburetor is the automatic choke valve control.

The ignition switches are on the electrical control panel, on the starboard side of the forward bulkhead in the crew's quarters.

f. WAIST AND TAIL COMPARTMENTS.—There are no flight controls in either the waist or tail compartments.




Figure 6—
Auxiliary
Power Plant
Control Panel

3. LOCATIONS AND ARRANGEMENT OF MISCELLANEOUS CONTROLS.

a. NOSE COMPARTMENT.

(1) **ELECTRICAL CONTROLS.**—The bomber's switch panel is located above and to the port side of the nose window. The panel is "L" shaped and extends back along the port side. On this panel are located: the gun sight power circuit breaker; projector light rheostat; firing key and utility receptacles; bomb release, bomb sight, manual, automatic, nose fuse and tail fuse switches.

The intervalometer is located on the port side, aft and below the bomber's switch panel. On this panel are located the intervalometer unit, pin jacks, and control switches. (See figure 59.)

(2) **INTERPHONE CONTROLS.**—The bombardier's station box for the interphone system is located on the starboard side, forward and near station 0.33.

(3) **ANCHOR GEAR.** (See figure 22.)—The anchor gear is stowed in a box on the port side of the hull between beltframe 0.33 and bulkhead 1. The reel is inside the anchor box.

Two men are required to cast and weigh anchor. One man is stationed inside the bomber's compartment. The other, equipped with a safety belt, is stationed on the mooring platform outside of the ship.

Note

Complete anchor handling instructions are printed on the inner face of the anchor compartment door, where it can be read by the man on the mooring platform, when the door is opened.

b. PILOT'S COMPARTMENT.

(1) **WINDSHIELD SPRAY AND WIPER.**—A hand pump with which to spray the windshields with alcohol anti-icing solution is located outboard of the instrument panel on the copilot's side. The pump handle controls a selector valve for right or left windshield.

A speed control box for control of the Marquette electric windshield wiper is located in the ceiling of the pilot's compartment, aft of the tab controls.

(2) ANTI-ICING.

(a) **PROPELLER.**—A rheostat (graduated in gallons per hour) for controlling the speed and output of the propeller anti-icer pump is located on the pilot's switch panel. The control knob turns clockwise to increase the amount of fluid delivered to the propeller.

(b) **WING.**—Switches for controlling the hot air wing anti-icing equipment are on the pilot's switch panel, next to the anti-icer rheostat.

(3) **VACUUM PUMP SELECTOR VALVE.**—A vacuum pump selector valve is located at the bottom of the instrument panel on the pilot's side. This valve shuts off vacuum to automatic pilot and copilot's turn and bank indicator.

(4) **PILOT'S AND COPILOT'S SEAT ADJUSTMENTS.**—The pilot's and copilot's seat may be adjusted for tilt and for fore and aft position by re-leasing spring-loaded locking pins controlled by levers. The levers for the tilt adjustments are located on the forward parts of the seats.

(5) **RUDDER PEDAL ADJUSTMENT.**—Both sets of rudder pedals may be adjusted for fore and aft

RESTRICTED
AN 01-5MC-1

- | | | | |
|---|--------------------------------|----|--|
| 1 | OUTSIDE AIR THERMOMETER | 10 | COWL FLAP CONTROL CRANKS |
| 2 | CLOCK | 11 | RIGHT ENGINE GAGE UNIT |
| 3 | EMERGENCY FUEL PUMP | 12 | LEFT ENGINE GAGE UNIT |
| 4 | FUEL MIXTURE CONTROLS | 13 | TACHOMETER |
| 5 | ENGINEER'S SWITCH PANEL | 14 | LEFT ENGINE MANIFOLD PRESSURE |
| 6 | CARBURETOR AIR CONTROL | 15 | LEFT ENGINE CYLINDER TEMPERATURE GAGE |
| 7 | PROJECTOR LIGHTS RHEDSTAT | 16 | ALTIMETER |
| 8 | FUEL SELECTOR VALVES | 17 | OIL QUANTITY GAGE |
| 9 | RIGHT ENGINE MANIFOLD PRESSURE | 18 | RIGHT ENGINE CYLINDER TEMPERATURE GAGE |




Figure 7—Engineer's Instrument Panel




Figure 8—Pilot's Control Yoke




Figure 9—Pilot's Switch Panel

position by releasing spring-loaded locking pins controlled by levers which may be moved with the feet. The levers are on the outboard side of each pedal.

(6) VENTILATION CONTROLS.—Openings in each side of the hull immediately aft of the instrument panel provide admission of fresh air during flight. These openings are closed with watertight hinged covers during take-offs and landings. Knobs controlling opening, closing and locking of the covers are immediately aft of the ventilators, within easy reach of the pilot and copilot. Pilot's and copilot's side windows have sliding panels which may be opened to obtain additional ventilation. The sliding panels may be latched in any position.

(7) ELECTRICAL CONTROLS.

(a) ELECTRICAL SWITCH PANEL.—The pilot's switch panel is directly over the door on the forward side of bulkhead 2. On this panel is located the anti-icer control rheostat, projector light rheostat and the following switches: anti-icer, pitot heater, torpedo's directional indicator, receptacle, bomb and torpedo, panel light, exterior light, port flare release, and starboard flare release. (See figure 9.)

(b) PILOT'S SIGNAL PANEL.—The pilot's signal panel is located on top and in the center of the pilot's control yoke. The switches and indicator lights for signalling the engineer and the pilot's instrument panel fluorescent light controls are located on this panel. (See figure 8.)

(c) WINDSHIELD WIPER CONTROL.—Refer to WINDSHIELD SPRAY AND WIPER, Section I, paragraph 3 b (1).

(d) RECOGNITION LIGHTS SWITCH.—

The recognition light switch box is located on the upper aft corner of the copilot's equipment panel. The copilot's equipment panel is located on the starboard side, outboard of the copilot's seat. (See figure 10.)

(e) FLOAT WARNING LIGHT.—The float warning light is located in the center of the pilot's instrument panel, between and below the manifold pressure gauges and directly over the automatic pilot panel.

(f) INTERPHONE CONTROL BOXES.—The pilot's interphone control box end jack box are located on the pilot's equipment panel, which is located on the port side of the airplane outboard of the pilot's seat. (See figure 46.)

The copilot's interphone control box and jack box are located on the copilot's equipment panel. (See figure 10.)


(8) RADIO CONTROLS.

(a) RADIO ALTIMETER SWITCHES AND LIGHTS.—The radio altimeter indicator lights are located on the starboard side of the automatic pilot controls, on the pilot's instrument panel.

The radio power switch is located on the pilot's switch panel.

The radio altimeter selector switch is located on the pilot's instrument panel on the starboard side, inboard of the landing gear warning lights and between the turn and bank indicator and hydraulic pressure gage.

(b) RADIO COMPASS CONTROL BOX.—The radio compass control box is located directly over the copilot's seat on the enclosure, just forward of the copilot's projector light and outboard of the fast feathering switches. (See figure 1.)



- ★ ★
- 1. IFF Identification Box
- 2. Interphone Control Box
- 3. Recognition Light Switch Box
- 4. Jack Box

★ ★

Figure 10—Copilot's Equipment Panel




Figure 11—Radio Controls on Bulkhead 2

(c) **MARKER BEACON INDICATOR LIGHT.**—The marker beacon indicator light is located above the automatic pilot controls and below and between the manifold pressure gauges.

(d) **PILOT'S COMMAND CONTROLS.**—The pilot's command transmitter control box is located on the forward face of bulkhead two, above the pilot's switch panel and to the starboard side of the center line of the airplane. (See figure 11.)

Two pilot's command receiver control boxes are mounted directly over the pilot's seat on the enclosure, to the port side of the fast feathering switches.

(e) **PILOT'S NAVIGATIONAL CONTROL.**—The pilot's navigational control box is located on the forward side of bulkhead two on the port side of the center line of the airplane and over the pilot's switch panel.

c. **RADIO OPERATOR-NAVIGATOR'S COMPARTMENT.**

(See figure 40.)

(1) **RADIO CONTROLS.**

(a) The master radio power switch is located on the radio operator's power box. The radio operator's power box is under the main distribution panel on bulkhead 4.

(b) The radio operator's key is located on the aft edge of the radio operator's table, inboard side. The radio operator's table is located below the main distribution panel.

(c) The antenna switch for the navigator's visual indicator is located on the stringers aft of bulkhead 3, forward and a little below the RAX-1 receivers.

(d) The radio operator's interphone control box is located on the forward side of bulkhead 4, between the radio operator's table and the main distribution panel.

(e) The drift meter is controlled by the master radio power switch. The drift meter is located forward of bulkhead 4 just aft of the navigator's table.

(2) **MAIN DISTRIBUTION PANEL.** (See figure 5.)—Located on the main distribution panel are the generator field emergency switches, anti-cinders and heaters switch, compartment lights and outlet switch, and fluorescent lights switch. The following switch type circuit breakers are also located on the main distribution panel: projector light, N-4 camera and gun sight, bomb sight, bomb release, remote compass, receptacle, table light, and radio compartment light. The table light and projector light rheostats are located under the circuit breaker switches on the inboard side of the panel. Below the rheostat are located five pin jacks that are for use with a portable precision type voltmeter. The lower portion of the panel is fitted with a utility receptacle and push button type circuit breakers for protection of the various circuits throughout the air-

plane. One additional circuit breaker (for the cooking stove) is located on the inboard side of the main distribution panel.

(3) **NAVIGATOR'S SWITCH BOX.**—The navigator's switch box is located over the outboard edge of the navigator's table, on the forward side of bulkhead 3. The navigator's chart-light switch and rheostat; and the utility receptacle and switch are located on this box.

(4) **FLUX GATE COMPASS.**—The "CAGE" and "UNCAGE" switch for the master flux gate compass is on the forward port side of bulkhead 4.

d. **ENGINEER'S COMPARTMENT.**

(1) **COOKING STOVE.**—There is a 24 volt dc stove on the starboard side of the airplane just aft of bulkhead 4. It has two hot plates with a "HIGH-LOW-OFF" electrical control switch for each.

(2) **PILOT-ENGINEER SIGNAL SYSTEM.**—These controls are located on the lower part of the engineer's switch panel. The engineer's switch panel is located on the upper part of the engineer's instrument panel. This signal system consists of switches located below small openings which are covered with ground glass and lettered as follows: "RAISE FLOATS," "LOWER FLOATS," "FULL RICH," "AUTO RICH," "AUTO LEAN," "STOP ENGINES," "RECALL," "INTERPHONE," and "SECURE." The switches below the indicator lights, or windows, control the particular function as indicated by the lettering on the windows above. This system is used to signal the pilot or copilot. When the engineer turns one of these switches, the pilot or copilot must acknowledge this signal by tripping his switch, which turns the light off.

(3) **MISCELLANEOUS ELECTRIC CONTROLS.**—Other electrical controls on the engineer's instrument panel are the compartment light switch, float warning light and the projector light rheostat.

The switches for the galley compartment light and for the utility receptacle are on the aft face of bulkhead 4, starboard side. The utility receptacle is located on the box that mounts these switches.

(4) **TAIL ANTI-ICING CONTROLS.**—The tail anti-icing fuel valve is immediately below the starboard window of the engineer's compartment.

e. **CREW COMPARTMENT.**—The auxiliary power plant control panel is located on the aft face of bulkhead 5 over the door and to the starboard side of the center line of the airplane. This panel contains the receptacle for the warning horn (inboard position) and the magneto switches for the auxiliary power unit.

On the forward face of bulkhead 6, on the port side near the top of the door, are located the switches for the crew compartment light and for the utility receptacle. The utility receptacle is mounted on the box that mounts the switches.

f. WAIST COMPARTMENT.

(1) The heat anti-icing damper control switch and indicator light is located on the forward side of bulkhead 7 above the door, just left of the center line of the airplane. (See figure 12.)

(2) The switches for the waist gun compartment light and for the utility receptacle are located on the aft side of bulkhead 6, on the port side near the top of the door. The utility receptacle is located inboard of these switches.

(3) The waist gunner's switch boxes are located on the longerons below the blisters, forward of the gun mounts on port and starboard sides. On these boxes are located the switches for the continuous feed motors and the switches for the gun-camera receptacles. A push button circuit breaker is located on these boxes for the illuminated gun sight. The receptacle for the gun-camera is located on the aft end of each box.

(4) A blister pump, located immediately aft of each waist gun blister, is used to inflate the water seals of the blisters. (See figure 13.)

The blister locking handle, located beneath the pump, operates the water seal outlet valve and the blister locking pin. The plunger of the water seal outlet valve rides on a cam actuated by the handle. The locking pin is actuated by a sector containing a slotted hole

and attached to the handle. Directions for operating the waterserial are posted on the port and starboard sides of bulkhead 7, on the forward face.

g. TAIL COMPARTMENT.

(1) The tail anti-icer switch box is located on the aft face of bulkhead 7 over the door on the port side. On this box are located the switches for the tunnel gunner's compartment light and for the utility receptacle. The utility receptacle is located below the switches on this box.

(2) The switch for the tail camera is located on the tail camera switch box. The tail camera switch box is mounted on the port side of the tunnel gunner's door on the stringers.

4. INSTRUMENTS.

a. BOMBER'S COMPARTMENT.—The following flight and navigation instruments are located on the bomber's instrument panel:

Air Speed Indicator
Altimeter
Free Air Thermometer
Inclinometer

b. PILOT'S COMPARTMENT. (See figure 1.)—The pilot has the following flight and navigation instruments on his side of the main instrument panel:

Air Speed Indicator
Altimeter
Directional Gyro
Gyro Horizon
Pilot's Directional Indicator
Radio Altimeter
Radio Compass
Rate of Climb Indicator
Remote Compass Indicator
Turn and Bank Indicator

The copilot has the following flight and navigation instruments on his side of the main instrument panel:

Air Speed Indicator
Altimeter
Directional Gyro
Gyro Horizon
Rate of Climb Indicator
Remote Compass Indicator
Turn and Bank Indicator

The Mark 3 Sperry automatic pilot control panel located in the center of the main instrument panel contains the following instruments:

Bank and Climb Gyro Control Unit
Directional Gyro Control Unit

The following engine instruments are located in the center of the main instrument panel above the Sperry Mark 3 automatic pilot control units:

Dual Tachometer
Manifold Pressure Gage (two)



Figure 12—Tail Anti-Icer Controls




Figure 13—Waterseal Inflation Mechanism for Waist Gun Blister

Other instruments located in the pilots' compartment are:

- Suction Gage—located on pilot's side of main instrument panel.
- Hydraulic Pressure Gage—located on copilot's side of main instrument panel.
- Oil Pressure Gage—located on bottom of automatic pilot panel.
- Clock—located on copilot's side of main instrument panel.
- Mark 8 Compass—located on center line of ceiling of pilot's compartment.

c. RADIO OPERATOR-NAVIGATOR'S COMPARTMENT.—The following instruments are located on the navigator's instrument panel:

- Air Speed Indicator
- Air Thermometer
- Altimeter
- Clock

Navigator's compass is located on the navigator's table.

d. ENGINEER'S COMPARTMENT. (See figure 7.)—The engineer has the following engine, fuel and oil instruments located on his instrument panel:

- Cylinder Temperature Gages (two)
- Dual Tachometer (one)
- Engine Gage Unit—incorporating oil temperature, oil pressure and fuel pressure gages (two)
- Manifold Pressure Gages (two)
- Oil Quantity Gage (one)

Other engine, fuel and oil instruments located in the engineer's compartment include:

- Fuel Flowmeters (two)—located above engineer's instrument panel
- Quantity Sight Gages (two)—located below front and rear wing spars
- Inclinometer (including tilt charts)—located on starboard wall

Additional instruments in engineer's compartment are:

- Altimeter—located on instrument panel
- Clock—located on instrument panel
- Outside Air Thermometer—located on instrument panel
- Anti-Icer Temperature Thermometer (three)—located on port wall

e. CREW'S QUARTERS.—A cylinder temperature thermometer and an oil pressure gage are located on the auxiliary power unit instrument panel located on the aft face of bulkhead 5.

f. WAIST COMPARTMENT.—There are no instruments in the waist compartment.

g. TAIL COMPARTMENT.—There are no instruments in the tail compartment.

5. GUNFIRE PROTECTION FOR PERSONNEL AND EQUIPMENT.

(See figure 14.)

Gunfire protection for personnel and equipment includes:

a. PILOT'S AND COPILOT'S ARMOR.—Homogeneous armor plate to protect pilot and copilot from gunfire from the rear is on pilot's and copilot's seat.

b. SIDE WAIST GUNNER'S ARMOR.—Face hardened armor plate is attached to each gun to protect the gunner.

c. TUNNEL GUNNER'S ARMOR.—Homogeneous armor plate in the aft part of the hull is to protect the gunner from fire from the rear.

d. SUMP ARMOR.—Homogeneous armor plate is installed at bulkhead 5, at the rear spar, and on the two sides of the superstructure to protect fuel sumps.

6. MOVEMENT OF FLIGHT PERSONNEL.

(See figures 20 and 42.)

Unrestricted movement of flight personnel from one end of the ship to the other is made possible by the central passageway. The watertight bulkhead doors should be left open, except in an emergency.

WARNING

Escape from the airplane during flight may be made through the waist gun blisters or the tunnel gun hatch.

When the airplane is on land or water, the hatches in the top of the bow turret and the pilot's compartment are available as additional escape hatches.

In operating the airplane, the pilot and flight engineer coordinate their activities through the interphone, or by means of the signal light system described in paragraph 2 of this section. The radio operator is responsible for checking the line switches and generator and battery bus switches on the main power distribution panel aft of his table.

The crew positions during cruising are as follows:

- One man at pilot's position
- One man at copilot's position
- One man at navigator's position
- One man at radio position
- One man at engineer's position
- One man in bunk
- One man at radar position
- One man at bow gunner's position

The battle positions of the crew are as follows:

- One man at bow position
- One man at pilot's position
- One man at radio position
- One man at engineer's position
- Two men at waist gun positions
- One man at tunnel gun position
- One man at the radar position




Figure 14—Angles of Armor Protection




Figure 15—Aileron Controls Diagram




Figure 16—Elevator Controls Diagram




Figure 17—Rudder Controls Diagram




Figure 18-Tab Controls Diagram




Figure 19—Controls Lock Diagram




Figure 20—Compartments, Windows and Flooring




Figure 21—Power Plant Controls





Figure 22—Anchor Gear Details



SECTION II PILOT'S OPERATING INSTRUCTIONS

1. BEFORE ENTERING THE PILOT'S COMPARTMENT.

a. **OUTSIDE THE AIRPLANE.**—Check to see that all engine covers, enclosure covers, etc., are removed and properly stowed.

If airplane is on land, check to see that wheel chocks are in place. Check to see that nose wheel is in a straight line with the keel. If airplane is moved during preparation for flight, repeat this check. Check to see that external nose and main landing gear locks have been removed.

Inflate main wheels to a pressure of 55 pounds, or if tires have deflection markers, inflate until deflection marker just touches the supporting surface.

The main gear shock struts are properly inflated when the distance from the gland nut in the cylinder to the red line on the piston is one and one-half inches.

Inflate nose wheel tire to a pressure of 35 pounds.

The nose gear shock strut is properly inflated when the distance from the gland nut in the cylinder to the red line on the piston is two inches.

See that all ice and snow is removed from wing and tail surfaces.

See that pitot head covers are removed. If pitot heads are iced over, turn on pitot heaters.

Entrance to the airplane on either land or water is gained through the waist gun blisters. Aft of each blister a step is held flush with the hull by a spring. To use, turn the step clockwise a quarter turn and pull outward; the spring latches it in the extended position. A rear entrance ladder, which is hung over the side just aft of the blister, is stowed inside, and may be used after initial entrance is gained.

Check supply of fluid in hydraulic system reservoir located in the starboard nacelle.

b. **INSIDE THE AIRPLANE.**—If the airplane is entered at night, the waist gun compartment light

switch, to the left of the door on the aft face of bulkhead 6, should be tried. Lights will go on if compartment light master switch and battery switch, both located on the main distribution panel, are set to the "ON" position; otherwise, no lights will work until someone goes forward and turns on the power.

Soon after going aboard, the auxiliary power unit should be started. This will insure ample power supply for lights, radio, cooking, etc. When the auxiliary power unit is started, be sure to open compartment ventilators overhead and see that they are left open until time for take-off.

If airplane has been out of service for several hours and is in water, search hull interior for signs of leaks. Any accumulated bilge water should be pumped out by use of the bilge pump and hose which are located forward of bulkhead 6 on the starboard side underneath the bunks.

Check gross weight and loading, and stow loads for proper balance as indicated by a balance computer. An instruction handbook is furnished with the computer.

Check to see that nothing interferes with movement of controls. Secure all loose gear.

OVERLOAD CAUTIONS

Do not exceed maximum allowable load.

Do not move C.G. so far as to endanger control or stability (see balance computer).

Stow load so as to prevent shifting or interference with controls.

Avoid concentrated loads on portions of structure not designed to bear them: i.e., flooring, midpoints of truss member, etc.

Avoid overloading plane or landing gear unless operating from smooth runway.

After rough water operations, particularly at gross weights in excess of 29,000 lbs, careful inspections should be made for any material damage.

Check fuel and oil quantity. Three switches must be operated to read oil tanks liquidometer. The battery switch on the main distribution panel must be on. The switch marked "OIL GAGE" on the mechanics panel must be on, and the selector switch turned to desired tank.

Fuel quantity may be checked by the two sets of sight gages, located in the mechanics compartment, and the proper conversion chart supplied with each airplane. (See figure 27.)

Check propeller anti-icing fluid reservoir.

Check supply of oil in auxiliary power unit oil tank.

Check batteries with hydrometer and voltmeter. Hydrometer reading should be 1250 or more. Voltage should be 24 volts or more.

Check conditions of all fire extinguishers.

Check fuel tank vapor dilution system to see if CO₂ cylinders are fully charged and red blow-out discs are intact.

Check supply of spare lamps and fuses.

Check food and water stowage, first aid kits, life jackets, life raft, parachutes, smoke grenades, and float lights.

Check supply of chemical toilet bags and toilet paper.

Make ground checks of radio, radar, and interphone equipment.

With the switch for remote compass indicators on, be sure that both dials read the same.

Check ammunition supply and flares. Be sure that flare doors operate properly.

Check condition of water seals on gun blisters.

Check all transparent windows and enclosures for visibility.

See that tail anti-icing air scoop is closed (push handle on bulkhead 7 all the way in).

See that all anti-icer switches are off.

Examine all logbooks and see if entries are up to date.

See that all cowling is properly fastened and that all inspection doors and covers are secured.

Check for presence of engine handcrank.

Check for presence of hydraulic pump handle and emergency landing gear "DOWN LATCH" lever.

2. ON ENTERING THE PILOT'S COMPARTMENT.

Check individual oxygen breather units. (See instructions given in Section V, paragraph 2.)

Unlock surface controls and stow control yoke locking bar. (See figure 23.) Check for freedom of action. Release parking brake.

Switch on all the pilot-engineer signal lights, first from the pilot's control yoke, then from the engineer's instrument panel, and check for burned out lamps.

Switch landing gear indicator light to "INDICATE," momentarily, for check.

Make the following special checks if night flying is contemplated:

Test every light on the airplane by switching on momentarily. Check to see that all line switches or circuit breakers for lights are on. Check for burned out fuses and bulbs.

Check supply of fluid in windshield spray reservoir.

Check flares in racks and extra flare supply.

Check signal pistol stowage and ammunition.

Check to see that blackout curtains are available for all windows.

Check for spare fluorescent light bulbs.

Check instrument dials for condition of luminous markings.

Make sure that there is at least one flashlight aboard.

Make check of all radio and interphone controls in pilot's compartment.

Be sure automatic pilot is turned off.

Adjust tab setting according to loading.

Work engine controls to check for freedom of action and leave set in proper positions for starting engines, as follows:

Propellers—Maximum rpm position

Cowl Flaps—Open

Mixture Control—"IDLE CUT-OFF"

Throttles—Approximately 800-1000 rpm

Order airplane headed into the wind. If airplane is on land, set parking brakes before starting engines. Check hydraulic system pressure gage to be sure there is at least 800 pounds pressure for brakes.

Check all instruments for proper pointer position. Check for dirty or broken cover glasses. Dirty glasses should be cleaned with a soft cloth.

Set altimeter to station altitude.

Set rate of climb indicator to zero.

Wind and set all clocks and navigation watches.

Check air speed indicator to see that pointer indicates zero, or value of wind velocity component in direction aircraft is heading.

Check gyro instruments "UNCAGED."

Before engines are started, check for air in automatic pilot hydraulic system.

Engage automatic pilot and attempt to move manual controls.

Controls should not be resilient (springy) when a moderate pressure is applied.

Note

Do not mistake stretching of cables for air in the hydraulic system. If in doubt, note whether there is any movement of the follow-up indices of the control units when pressure is applied.

Test windshield wipers to be sure that they work.




Figure 23—View of Pilot's Compartment Showing Controls Locked

3. FUEL SYSTEM MANAGEMENT.

(See figure 26.)

a. DESCRIPTION.—The wing center section contains two integrally built sealed chambers with a total usable fuel capacity of 1750 U. S. (1457 Imperial) gallons.

(1) SELF-SEALING CELLS.—Provision is made for installation of self-sealing cells in either or both of the two chambers. A tank dumping and CO₂ purging system is installed in the integral tanks.

The fuel tank plan provides for installation of five self-sealing cells in the starboard tank of all odd numbered airplanes, and in the port tank of all even numbered airplanes as they leave the factory. Cells can be installed however in both tanks, or may be completely removed, as required. The cells fit into the tank (left or right) for which they are designed, and are not interchangeable.

When cells are installed on one side only, the maximum capacity of the cells plus the remaining integral tank is 1497 U. S. (1242.5 Imperial) gallons. When cells are installed in both tanks, the maximum capacity (water-borne) is 1244 U. S. (1032.5 Imperial) gallons.

(2) SELECTOR VALVES. (See figure 24).—The fuel flow from the tanks to the engines is controlled by the selector valves on the engineer's panel. The port valve can be set to feed fuel from either or both tanks to the port engine. The starboard valve can be set to feed fuel from either or both tanks to the starboard engine.

(3) HAND WOBBLE PUMPS.—Connected to the selector valves, and also mounted on the engineer's panel, are the A.E.L. units, incorporating strainers and the two hand wobble pumps. The wobble pump handles are so designed that both pumps can be operated simultaneously with one hand, or separately, as desired.

(4) STRAINERS AND DRAINS.—The strainers are incorporated in the A.E.L. units and are provided with drain cocks, with controls on the engineer's panel, so that they may be drained during flight.

(5) AUXILIARY POWER UNIT, CENTRAL HEATER, and TAIL ANTI-ICER FUEL SUPPLY.—A separate selector valve for the auxiliary power unit fuel supply is located just below the starboard fuel selector valve on the engineer's panel.

A shut-off valve for the central heater is located on the ceiling of the Radio Operator-Navigator's Compartment just forward of the aft bulkhead.

A shut-off valve, filter, and pressure regulator for the tail anti-icer fuel supply are located under the starboard window of the engineer's compartment.

(6) FLOWMETERS.—Two direct-indicating type flowmeters, with bypass controls are mounted at the top of the engineer's control panel.

The rate of fuel flow through the meters is indicated by the calibrated scales on each side of the transparent tube. The calibrations on the left-hand scale of each flowmeter indicate gallons per hour based on the use of aviation grade gasoline, specific gravity 0.71 at a temperature of 39°C (102°F). The right-hand scale is calibrated to read pounds per hour. The gallons per hour is accurate only at the temperature and specific gravity given above.

The rate reading is given when the float, or flow indicator within the tube, rises as the rate of flow increases, or drops as the rate of flow decreases.

The bypass valve and handle on each flowmeter permits complete isolation of the meter from the fuel system. When the bypass handle is pulled out, fuel passes directly from the inlet port to the outlet port. When the handle is pushed in, the flow is directed through the flowmeter and flow rate is indicated by the float.

In the upper fittings of the flowmeters are located vent valves for use in case of air-binding or vapor lock.


(7) PRIMER.—Engine priming is accomplished by means of a hand priming pump on the port side of the engineer's compartment.

(8) ENGINE-DRIVEN PUMPS.—When the engines are running, fuel pressure is supplied by the two engine-driven pumps. Each pump has a relief valve set to short-circuit fuel flow from the discharge port directly back to the intake port, when the fuel pressure rises higher than approximately 18 pounds per square inch.


(9) CROSS-FEED.—A cross-feed system is provided for use in case of failure of either of the engine-driven pumps. The cross-feed valve makes it possible to direct fuel from the one functioning pump to the carburetors on both engines.

(10) DRAIN AND REFUEL PROVISIONS.—Tank drain and refuel lines are installed in both tanks. They can be used for refueling only when fuel cells are not installed in the tanks. By attaching a one-inch pipe fitting to the outer terminal of either drain line, the line can be used to drain the tanks.

(11) FUEL DUMPING PROVISIONS.—Fuel dumping is provided in the airplane so that when the plane is proceeding to the objective on a mission it may use the fuel in the integral tank, but just prior to encountering enemy fire the remaining fuel in the integral tank may be dumped and the tank immediately purged, because of the fire hazard of the fuel vapor. The dump valve is operated by a lever and cable. The lever is located directly over the engineer's head. Fuel can be dumped only from integral tanks. Dump valves and ducts are installed on the starboard sides of all even numbered airplanes, and on the port sides of all odd numbered airplanes as they leave the factory.



FUEL CONTROL POSITIONS WITH CROSS-FEED VALVE 'OFF'



FUEL CONTROL POSITIONS WITH CROSS-FEED VALVE 'ON'

(NOTE: CROSS-FEED VALVE TO BE "ON" ONLY IF PUMP FAILS.)




Figure 24—Fuel Selector Valve Position Chart





Figure 25—Oil System Diagram



- | | | |
|----------------------------------|---|---|
| 1. Cross-feed Selector Valve | 26. Filler Neck Cover | 50. Starboard Fuel Mixture Control |
| 2. Strainer Drain Valve - | 27. Vent Stand Pipe—Tank | 51. Starboard Fuel Wobblometer |
| 3. Aux. Power Unit Fuel Line | 28. Fuel Tank Manhole Cover | 52. Starboard Wobble Pump Handle |
| 4. A.E.L. Unit | 29. S.S. Cells Vent Tubes | 53. Engineer-Pilot Visual Signal Panel |
| 5. Fuel Selector Cock | 30. Purging Cylinder Pull Handle | 54. Starboard Carburetor Air Control |
| 6. Flowmeter | 31. Purging Cylinder | 55. Starboard Eng. Cyl. Temp. Gage |
| 7. Main Fuel Shut-off Valve | 32. Pressure—Relief Line | 56. Starboard Fuel Selector |
| 8. Cross-feed Fuel Line | 33. Pressure—Relief Disk | 57. Aux. Power Unit Selector |
| 9. Center Line of Wing | 34. Self-Sealing Fuel Cells | 58. Starboard Eng. Manifold Press. Gage |
| 10. Main Fuel Line to Engine | 35. Primer Pump | 59. Starboard Tachometer |
| 11. Fuel Pressure Line | 36. Dump Valve Control Cable | 60. Starboard Strainer Drain Selector |
| 12. Vent Line to Pressure Gpge | 37. Fuel Line to Primer Pump | 61. Starboard Fuel and Oil Press. Gage |
| 13. Engine Primer Line | 38. Fuel Line to Central Heater | 62. Port Fuel and Oil Pressure Gage |
| 14. Vent Line—Tank to Carburetor | 39. Fuel Cell Manifold Inspect'n Window | 63. Port Tachometer |
| 15. Engine—Driven Fuel Pump | 40. Fuel Cell Manifold Access Doors | 64. Cross-feed Selector |
| 16. Carburetor | 41. Sight Gage Inspection Window | 65. Oil Quantity Gage |
| 17. Carburetor Elbow Scoop | 42. Main Tank Drain Outlet | 66. Altimeter |
| 18. Primer Line Spider | 43. Shut-off Valve—Tank Drain | 67. Port Strainer Drain Selector |
| 19. Check Valve—Dump Duct | 44. Main Tank Drain and Refueling | 68. Port Engine Cylinder Temp. Gage |
| 20. Dump Valve | 45. Sump Drain Plug | 69. Port Fuel Selector |
| 21. Dump Duct | 46. Main Fuel Line From Sump | 70. Port Carburetor Air Control |
| 22. Integral Fuel Tank | 47. S.S. Cell Manifold Lines | 71. Outside Air Temperature Gage |
| 23. Dump Valve Control Lever | 48. Port Flowmeter | 72. Clock |
| 24. Vapor Dilution Line | 49. Port Fuel Mixture Control | 73. Port Wobble Pump Handle |

Figure 26—Fuel System Diagram

Each integral tank is equipped with purging provisions, consisting of a carbon dioxide cylinder, a pull handle, and the necessary tubing to carry the carbon dioxide gas into the tank. The pull handle is mounted immediately aft and to the right of the engineer's seat.

(12) FUEL SIGHT GAGES. (See figure 27.)—Fuel quantity is indicated by the two sets of sight gages. One pair is under the wing front spar, immediately aft of the engineer's instrument panel. The other pair is under the wing rear spar, aft of the engineer's seat. Each sight gage is equipped with a shut-off valve at the top of the tubes and a drain valve in the bottom of each tube. An inclinometer to guide the engineer in making corrections to the sight gage readings at different longitudinal attitudes of the airplane is located on the starboard side of the engineer's compartment.

(13) FUEL PRESSURE GAGES.—Fuel pressure is indicated by the fuel pressure gages which form parts of the two engine gage units on the lower center of the engineer's instrument panel.

b. OPERATION.

(1) READING THE FUEL SIGHT GAGES.—The fuel sight gages are calibrated to show the quantity of fuel in U. S. gallons. When self-sealing cells are installed, the calibration for the gages attached to the cell side of the wing will differ from the calibrations on the gages for the opposite tank.

The two inside gage tubes show fuel quantities in the tanks from full to half full. Readings are calibrated at the center of the gage plate for the inside tubes. The two outside tubes indicate fuel quantities from the half full to empty ranges. Readings are taken from the outside calibrations on the plate.

Gage scales are calibrated to read correctly the contents of tanks or cells when the chord line is at an angle of $3\frac{1}{2}$ degrees to the ground line. The rear gage only, is to be used after fuel has dropped to 100 U. S. (83.25 Imperial) gallons in the integral tank, or 75 U. S. (62.5 Imperial) gallons in the cells.

Use of the inclinometer, mounted on the starboard side of the engineer's compartment, and use of the tilt charts above the inclinometer, are required to make accurate readings of the sight gages.

Example

Forward gage reads 500 gallons. Rear gage reads 600 gallons. Inclinometer shows airplane tilted at 7° . Tilt chart for front gage shows correction for 500 gallons (reading at 7° tilt) is 545 gallons. Tilt chart for rear gage shows correction for 600 gallons (reading at 7° tilt) is 545 gallons also. Actual quantity of fuel is therefore, 545 gallons.

(2) FLOWMETER OPERATION.—For normal operation the flowmeters are always bypassed. (Bypass valve handles pulled out.) The bypass valve handles are pushed in only long enough to take a reading.

(For normal consumption rate of fuel under various flight conditions, see figure 63.)

(3) OPERATION OF FUEL SELECTOR VALVES.—The various combinations of tank-to-engine fuel flow are shown in figure 24.

(4) OPERATION OF CROSS-FEED SYSTEM.—The various combinations of fuel selector valve settings with only one fuel pump operating, and the cross-feed valve "ON" are shown in figure 24. The cross-feed valve should always be "OFF" except in case of pump failure.

(5) OPERATION OF HAND WOBBLE PUMPS.—The hand wobble pumps are used to furnish fuel pressure to start the engines and to furnish emergency pressure in case one of the engine-driven fuel pumps is disabled. Pump capacity is 135 U. S. (112.5 Imperial) gallons per hour at 120 single strokes per minute.

(6) OPERATION OF PRIMING PUMPS.—The hand priming pump is on the port side of the engineer's compartment. The pump handle can be turned to select the engine to be primed. To unlock the plunger, push the handle all the way down; turn to right or left "ON," as desired. Plunger may then be pulled back for the stroke.

Number of priming strokes required for starting will vary from no prime with a hot engine to six, eight, or more strokes with very cold engines. Excessive priming will load the cylinders with raw gasoline, making it difficult to start the engine. Underpriming is usually indicated by backfiring of the engine through the intake system, with attendant hazards.

Always make certain that the primer pump is locked in "OFF" position before engine is started. A vacuum check prevents suction of fuel into the engine if the primer is accidentally left in the "ON" position; the engineer should check to see that the plunger is locked "OFF" as a safety precaution. To shut off, push the handle all the way in and turn to "OFF."

(7) MIXTURE CONTROL.—The engines are equipped with Bendix-Stromberg carburetors of the PD-12H series, having automatic mixture control which may be set for "FULL RICH," "AUTOMATIC RICH," "AUTOMATIC LEAN," or "IDLE CUT-OFF."




Figure 27—Fuel Sight Gauges

"AUTO-LEAN" should be used when cruising at Maximum Cruising Power or less, provided cylinder head temperatures can be kept below 232°C. (450°F.). At all other times, "AUTO-RICH" should be used.

"FULL-RICH" is provided for use in emergencies only. The automatic mixture control is by-passed in this position. Unless failure of the automatic mixture control occurs, it is very unlikely that any occasion for use of "FULL RICH" will be encountered.

"IDLE CUT-OFF" shuts off discharge of fuel to the engine. It serves both to shut down the engine and to prevent inadvertent flooding while the engine is not running.

Before cruising in "AUTOMATIC LEAN" the engines should be cooled down to 232°C (450°F). Refer to figures 31, 63 and 64 for recommended manifold pressures and rpm settings to be used for cruising in "AUTOMATIC LEAN."

CAUTION

Fuel will flow through the carburetor when the mixture control is in any position except "IDLE CUT-OFF." This is true whether the engine is running or has stopped. Therefore, the mixture control should be left in "IDLE CUT-OFF" position whenever engines are stopped.

(8) FUEL SPECIFICATION.—The engine calibrations and flight operation data in this handbook are based on fuel of specification AN-F-28, Grade 100/130. The self-sealing cells and hoses installed are resistant to aromatic fuel compounds.

(9) FUEL DUMPING PROCEDURE. — Pull dump valve control handle down until it locks in this position. The purging system handle must be pulled immediately after fuel dumping is completed. It is important that there be no delay, due to the fire hazard of the fuel vapor.

CAUTION

Once the purging handle is pulled, the CO₂ cylinder will be completely discharged, and must be replaced or recharged before another dumping operation can be performed.

4. STARTING ENGINES.

PILOT

b. Instruct radio operator to start auxiliary power unit (see Section V, paragraph 7) and to check for proper volt-meter and ammeter readings for unit.

c. Set propeller in "LOW PITCH" (high rpm).

d. Set interphone control switch in "ICS" position.

e. Signal flight engineer to prepare to start starboard engine. Hydraulic pump is connected with this engine.

FLIGHT ENGINEER

a. Turn engines over by hand several revolutions to clear bottom cylinders. It is advisable to remove the lower spark plugs if there is reason to believe the bottom cylinders are loaded.

f. MIXTURE CONTROL.—Set in "IDLE CUT-OFF" position.

g. COWL FLAPS.—Set fully open.

h. FUEL VALVES.—Set fuel valves for "LEFT ON" and "RIGHT ON."

i. Check for current at starters by momentarily turning starter switch to "START" position and listening for slowdown of A. P. U. or sound of starter.

PILOT

FLIGHT ENGINEER

- k. THROTTLE.—Set at 800 to 1000 rpm position.
- p. Close individual engine ignition switch on signal from engineer.

- v. THROTTLE.—If engine is flooded, open throttle wide at request from engineer.

CAUTION

- Be prepared to retard throttle quickly in case engine fires. If engineer opens mixture control and resumes pumping with wobble pump, engine might run away if throttles are open.
- x. THROTTLE.—As soon as engine starts, adjust throttle as low as possible for the first 30 seconds after starting. Stand by for engineer's report on oil pressure.
- z. THROTTLE.—After the first half minute, adjust the throttle to about 1000 rpm.

- j. CARBURETOR AIR CONTROLS.—Set in "DIRECT" position.

- l. PRIME WITH PRIME PUMP.—As many as six or eight strokes of the primer may be necessary if engine is cold.
- m. FUEL PRESSURE.—Fuel pressure should be 10 to 15 pounds per square inch with hand wobble pump.
- n. Energize starter 12 to 15 seconds by holding starter switch in "START" position.
- o. Signal pilot for "CONTACT."

- g. Engage starter by moving switch to "MESH" position.

- r. MIXTURE CONTROL. — Shift to "AUTOMATIC RICH" without hesitation as soon as engine starts firing. If engine stops, return to "IDLE CUT-OFF" immediately.

- s. Notify pilot when oil pressure is up. If not up in 30 seconds, notify pilot and shut engine off.

- t. FAILURE TO START.—If engine does not start almost immediately (three seconds), repeat use of hand primer and wobble pump.

- u. FLOODED ENGINE.—Flooding is generally indicated by a discharge of fuel from the engine blower case drain, or by presence of raw gasoline in the exhaust. To clean engine, discontinue use of wobble pump, request pilot to open throttle wide, and turn engine over with starter.

- w. FUEL PRESSURE.—As soon as engine starts, move mixture control to "AUTO RICH," continuing to operate wobble pump vigorously until the engine runs smoothly, and automatically builds up fuel pressure of 16 to 18 pounds per square inch.

- y. PRIMER.—Be sure primer pump handle is locked after engine has started.

5. ENGINE WARM-UP AND ACCESSORY CHECK.

PILOT

b. Warm up engine at 1000 rpm if oil pressure is up. Propeller should be in highest rpm position.

e. CHECK PROPELLER OPERATION.—Pull propeller governor control back to extreme high pitch (low rpm). Move slowly forward again to extreme low pitch (high rpm). Check operation of feathering mechanism by feathering and unfeathering once.

g. Check the drop in revolutions for each engine when moving the magneto switches from "BOTH" to "LEFT" or to "RIGHT." (Check at 2000 rpm and 25 inches Hg) Drop in rpm may be 50 to 75 (100 rpm maximum). After checking one magneto, switch to "BOTH" for a few seconds before checking the other magneto. Check moving switch from "LEFT" to "RIGHT" or "RIGHT" to "LEFT." Drop should not be more than 30 to 40 rpm. Make magneto check in as short a time as practicable. Check center (emergency) switch momentarily off.

j. THROTTLE.—Set throttle for 2000 rpm and request engineer to check engine instruments. Because engine cooling on the ground is usually insufficient at this speed, instrument check should be made in as short a time as possible.

k. Taxi into water at this point if water take-off is contemplated.

p. HYDRAULIC PRESSURE GAGE.—The hydraulic pressure gage should read 800 to 1000 pounds.

FLIGHT ENGINEER

a. COWL FLAPS.—Leave open under all conditions. Do not attempt to accelerate warm-up by closing cowl flaps.

c. Check oil pressure at 1000 rpm. It should be 40 pounds minimum.

d. After oil is warm (40°C or above) check oil pressure at 1500 rpm. Minimum pressure should be 65 pounds; maximum should be 105 pounds.

f. Check carburetor air control to "DIRECT" position except when there is danger of icing, or sand or dust is blowing.

h. Make idle mixture check with throttle set for 800 rpm. Move the mixture control lever smoothly and steadily into the "IDLE CUT-OFF" position and observe the tachometer for any change in rpm. Return the mixture control lever to the "AUTO RICH" position before the engine cuts out. A rise of more than 10 rpm indicates too rich an idle mixture, and no change or a drop in rpm indicates that the mixture is too lean. A rise of 5 to 10 rpm is recommended in order to permit idling at low speeds without danger of fouling plugs and at the same time to afford good acceleration characteristics.

i. Check to see if floats are down and locked when on water.

l. Second mechanic should secure ladder and close hatches if on water.

m. OIL PRESSURE.—Oil pressure should be 85 (+15, -5) pounds at 2000 rpm.

n. FUEL PRESSURE.—Fuel pressure should be from 16 to 18 pounds.

o. CYLINDER TEMPERATURE.—Do not exceed 232°C (450°F) during ground check.

q. If there is sufficient time, have canvas scoop rigged to tail anti-icer air scoop, and check operation of tail anti-icer.

PILOT

r. AUTOMATIC PILOT.—Check automatic pilot as follows:

- (1) Vacuum gage should read 3.75 to 5 inches Hg.
- (2) See that four-way oil valve, to pilot's left, is "ON," and that oil pressure gage shows pressure (150 pounds at 1000 rpm engine speed).
- (3) Uncage bank and climb gyro. (Turn caging knob counter-clockwise as far as it will go.)
- (4) Set and uncage directional gyro control. (Push caging knob in and turn to set lower card to desired heading, then pull knob out.)
- (5) Turn rudder knob on directional gyro control to align upper card with lower card.
- (6) Turn aileron knob until follow-up index on top of bank and climb gyro dial matches zero point on banking scale.

Note

If airplane is on the water, one float or the other will be down and the airplane will be tilted laterally; the number of degrees will be indicated by the inclinometer under the directional gyro. Aileron index should be set for same number of degrees deflection.

Warn pilot to discontinue ground check of automatic pilot system if engine cylinder temperatures and oil temperatures are rising above safe limits.

- (7) Turn elevator knob until the follow-up index matches the elevator alignment index at the side of the bank and climb gyro dial.

CAUTION

Do not align follow-up index with the horizon bar.

(8) Make sure that surface controls operate freely. Engage automatic pilot with "ON-OFF" lever at top of pilot's compartment. Move lever SLOWLY all the way "ON."

(9) Oil pressure on gage should read 150 (± 10) pounds.

(10) Check operation of automatic pilot by rotating rudder knob each way. The servo speed control valve settings will determine the speed of control.

(11) Check for air in automatic pilot hydraulic system. Controls should not be resilient (springy) when a moderate pressure is applied to them, but should feel as though locked. If air is present, remove it.

Note

Do not confuse stretching of cable with the presence of air in the hydraulic system. If in doubt, note whether there is any movement of the follow-up indices of the control units. Stretching of the cable will not cause these indices to move.

(12) Check to see if automatic pilot can be overpowered manually without excessive force on the controls.

(13) Disengage automatic pilot.

(14) GYRO HORIZON AND DIRECTIONAL GYRO.—Check gyro instruments not included in automatic pilot control panel. Uncage gyro horizon and check to see that there is no precession, and that instrument indications will be that of the airplane's position. Set and uncage directional gyro. (See instructions above for directional gyro on automatic pilot panel.) Check for instrument drift of not more than 3° in 15 minutes.

PILOT

u. If immediate take-off is contemplated, order all hatches and ventilators secured. If on water, make sure anchor gear is stowed, mooring lines clear, and gun blister waterseals inflated. If on land, see that wheel chocks are removed, entrance ladders stowed, and that nose wheel is pointed straight ahead.

v. Determine if continued use of auxiliary power unit will be necessary, and, if not, shut off unit.

w. If on land, check to see that floats are up and securely latched. If on water, check to see that floats are securely latched in down position.

x. Check with someone aft to see that tail anti-icer air scoop is closed, and that anti-icer switch is off. See that temporary canvas scoop is removed and stowed.

FLIGHT ENGINEER

s. Request radioman to switch on main engine generators and batteries and to read meters to check for proper power output (28 to 28.5 volts with no load).

t. Check operation of galley stove by turning one hot plate on "HIGH" position and the other on "LOW" position, and note the differences in heat; then reverse switches and repeat check.

6. EMERGENCY TAKE-OFF.

(See Section IV, paragraph 3.)

7. ENGINE AND ACCESSORIES OPERATION GROUND TEST.

(See Section II, paragraph 5.)

8. TAXIING INSTRUCTIONS.

a. GENERAL.—Taxiing should not be done at very low or very high rpm. No restriction can be placed on taxiing rpm, but it should be noted that a large part of ignition trouble may be due to overheating the installation by taxiing at high speeds.

Automatic rich mixture is desirable for cool ground operation.

Cowl flaps should be open for all taxiing operations.

In using engines, a little power applied for longer periods is better than repeated short surges of power, which tend to empty the accelerator pump if sufficient time is not allowed for the pump to refill.

b. LAND TAXIING.—The landing gear may be used for taxiing into and from the water.

Taxiing on land should be done without brakes wherever possible, as application of brakes for long periods will cause overheating.

WARNING

Emergency hydraulic hand pump handle must be in operating position before taxiing.

Sudden applications of either brake or power should be avoided, as they tend to jerk the nose wheel around, and may damage the gear.

The nose wheel is free to swivel a maximum of 30° each way; the airplane can be turned either way while taxiing at a fast rate, without showing a tendency to ground loop, even in wet weather. However, turns should be anticipated sooner than with conventional gear by speeding the outside motor well before the turn and applying the inside brake easily, if necessary.

CAUTION

In making small radius turns avoid locking inside wheel with resultant tearing of rubber.

One of the main points to consider in taxiing tricycle installations is to avoid starting movement contrary to the direction in which the nose wheel is turned. Pilots should note the position of the nose

wheel before entering the airplane. If it is turned side-wise over 30° or caught in a rut, the wheel should be straightened before attempting to taxi. If turned only slightly, the pilot should begin his taxiing in the direction the nose wheel points in order to start it castering. After the nose wheel has begun to caster, the plane may be turned in the desired direction. Pilots should start taxiing with not more than the minimum amount of throttle required to start motion. This is necessary to avoid applying heavy loads on a canted nose wheel. Particular care must be exercised when operating in muddy ground, soft sand, or deep snow.

The nose wheel is dampened against shimmying, and none should be tolerated, since it can be cured by proper servicing. Before each day's first land take-off the airplane should be taxiing for some distance in a straight line to test the nose wheel for shimmying tendencies.

The main landing gear is located at approximately 41.6 per cent of the mean aerodynamic chord. Center of gravity locations forward of this point obviously will have no tendency to rock the airplane and lift the nose wheel off the ground. Brakes should not be used during a take-off run. Course corrections should be made with slight throttle changes.

CAUTION

If the brakes have been used to any great extent prior to taxiing to the line, it is advisable to allow them to cool before applying the parking brakes.

c. WATER TAXIING.—Water taxiing is possible at higher rpm settings than on land because of the constant drag of the water.

9. TAKE-OFF.

a. LAND TAKE-OFF.—Tricycle-gear planes will not take themselves off. When elevator control is gained, the nose wheel should be lifted from the ground, and the run continued on the main wheels until take-off speed is reached.

The take-off speed varies with the gross weight of the airplane. At 27,000 pounds, the take-off speed is 63 knots, and at 34,000 pounds, it is 71 knots.

Maximum recommended gross weight for take-off from a smooth, prepared runway is 34,000 pounds, but with a jettisonable load of approximately 2000 pounds the maximum is 36,400 pounds. Appropriate reductions of weight down to 26,000 pounds must be made for less favorable conditions.

★

★

★

CHECK-OFF LIST—LAND.

PILOT

FLIGHT ENGINEER

(1) Check elevator, rudder, and aileron tab settings.

(2) Check emergency hydraulic hand pump handle in operating positions.

(3) Move landing gear indicator switch to "INDICATOR LIGHT." (See figure 28.)

(4) Check to make certain rudder control is unlocked and rudder operates freely.

(5) Check automatic-pilot "OFF."

(12) Propellers should be set for 2700 rpm (maximum 2750 rpm, surge). Manifold pressure should be 48 inches Hg maximum). (grade 100/130 fuel).

(14) Reduce rpm immediately after take-off to 2550. Maintain 42 inches Hg manifold pressure.

(15) Raise wheels as soon as possible after take-off.

(16) Check "WHEELS UP" and "WHEEL DOOR LOCKED" by moving indicator light switch to "INDICATE."

(17) Move landing gear indicator switch to "WARNING LIGHT."

(19) Turn off lights which do not show functional parts.

(6) Check "FLOATS UP."

(7) Check oil pressure and oil temperature normal. Minimum temperature should be 40°C (104°F).

(8) MIXTURE CONTROL.—Set at "AUTOMATIC RICH."

(9) CARBURETOR AIR CONTROL.—Set for "DIRECT" air except when ice or sleet conditions require "ALTERNATE" setting.

(10) Cowl Flaps should be set at "OPEN" in order that cylinder temperature before take-off will not exceed 232°C (450°F).

(11) Report to pilot when ready.

(13) COWL FLAPS.—Adjust to maintain cylinder temperature not to exceed 260°C (500°F) for one hour or 232°C (450°F) for continuous cruising; 20°C (36°F) or more below the maximum for each condition is preferred.

(18) If auxiliary power unit is being used, have ventilators in crew's quarters opened after take-off is completed.






Figure 28—Landing Gear Indicator System

b. WATER TAKE-OFF.—This take-off speed varies with the gross weight of the airplane. At 27,000 pounds, the take-off speed is 63 knots, and at 34,000 pounds it is 71 knots.

Maximum recommended gross weight for rough operation is 27,300 pounds; for smooth water operation, 34,000 pounds. At gross weights in excess of 30,000 pounds, the limiting weight which may be taken off safely will depend on hydrodynamic considerations.

CHECK-OFF LIST—WATER.

PILOT

(1) Check elevator, rudder, and aileron tab settings.

(2) Check to make certain rudder control is unlocked and rudder operates freely.

(3) Check automatic pilot "OFF."

(4) Check wing anti-icers off. Signal navigator to close central heater outside air duct. Signal crew member to turn off tail anti-icer and close air scoop. Crew member to check all hatches and openings closed and bomber's window cover in place.

(5) Check to see if landing gear is up and locked by moving indicator light switch to "INDICATE."

(12) Propeller should be set for 2700 rpm (maximum 2750 rpm, surge). Manifold pressure should be 48 inches Hg maximum. (glade 100/130 fuel).

(14) Reduce rpm immediately after take-off to 2550. Maintain 42 inches Hg manifold pressure.

FLIGHT ENGINEER

(6) Check "FLOATS DOWN."

(7) Check oil pressure and oil temperature normal. Minimum temperature should be 40°C (104°F).

(8) MIXTURE CONTROL.—Set at "AUTOMATIC RICH."

(9) CARBURETOR AIR CONTROL.—Set for "DIRECT" air except when ice or sleet conditions require "ALTERNATE" setting.

(10) COWL FLAPS should be set at "OPEN" in order that cylinder temperatures before take-off will not exceed 232°C (450 F).

(11) Report to pilot when ready.

(13) COWL FLAPS.—Adjust to maintain cylinder temperatures not to exceed 260°C (500°F) for one hour or 232°C (450°F) for continuous cruising; 20°C (36°F) or more below the maximum for each condition is preferred.

(15) If auxiliary power unit is being used, have ventilators in crew's quarters opened after take-off is completed.

10. ENGINE FAILURE DURING TAKE-OFF.

(See Section IV, paragraph 4.)

11. CLIMB AND HIGH SPEED LEVEL FLIGHT.

For maximum performance (rated power) the pro-

PELLER should be governed to 2550 rpm, the mixture control set at "AUTOMATIC RICH," and the manifold pressure reduced gradually from 42 inches Hg at Sea Level to 39.5 inches Hg or Full Throttle at 7000 ft.

After a long climb, or after going to a higher power in cold weather, momentarily reduce the propeller pitch (increase rpm) to permit hot engine oil to clear out of the mechanism.

12. GENERAL FLYING CHARACTERISTICS.

The airplane is stable over a wide range of center of gravity locations; however, care should be exercised to operate controls smoothly when flying with the center of gravity near the limits of its range.

At high speeds, the elevators become "heavy," helping to prevent sudden extreme application of the elevator control, which might prove damaging to the structure.

Banks up to 60° can be made safely.

It is good practice to slow down to 100 knots in extremely turbulent air.

a. FLIGHT RESTRICTIONS.—Do not exceed an engine speed of 2700 rpm (five minutes only). However, 3060 rpm is permitted for 30 seconds in a dive.

Do not exceed an engine speed of 2550 rpm for continuous flight.

Do not operate engines in excess of 67% power with the mixture control in the "AUTOMATIC LEAN" position.

Do not operate automatic pilot when one or more engines are not delivering normal power. It is not necessary to disengage the automatic pilot when encountering rough or turbulent air. If necessary, adjust the speed control valves to improve operation. Under extremely turbulent conditions, follow through manually on the controls and assist the automatic pilot if necessary.

Do not use the automatic pilot when flying at less than an indicated air speed of 85 knots.

Do not operate the airplane under control of the automatic pilot without at least one rated pilot "on watch."

Restricted speeds and accelerations for gross weights in excess of 26,000 pounds are given in Section III, paragraph 2.

b. ELEVATOR TRIM.—Five degrees deflection of the elevator trim tab is usually sufficient to trim the airplane in any power condition, including landing gear or floats extended.

c. CRUISING.—While cruising operations may be conducted at any engine power below normal rated power, in order to obtain low fuel consumption it is recommended that all cruising operations be conducted below 700 horsepower. When cruising at 700 horsepower the engine speed should be 2170 rpm, which results in 140 bmep; the mixture control should be in the "AUTO RICH" position. When cruising below maximum cruising power, the speed should be adjusted so as not to exceed 140 bmep, and the mixture control

should be in the "AUTO LEAN" position. The cylinder head temperature limit of 232°C (450°F) must not be exceeded during cruising operation. (Refer to figure 62.)

13. PROHIBITED MANEUVERS.

Loop	Wing Over
Chandelle	Vertical Turn
Immelmann Turn	Inverted Flight
	Spin

14. STALLS.

a. STALL CHARACTERISTICS.—With or without power, the airplane settles as it approaches the stall. The stall is very gradual, showing no tendencies to whip.

Indication of approaching stall is a slight tail shake, increasing as the stall becomes more evident. Both lateral and directional stability are completely maintained throughout the stall. No shake or loss of control is noticed either in the rudder or aileron. The airplane does not have any severe stalling characteristics. In a normal power-on or power-off stall, the airplane merely mushes down and the recovery is almost instantaneous. However, in more abrupt stalls, a pronounced nose-down fall-off is noticed. The stalling characteristics of any airplane depend upon such items as cowl flap position, landing gear and float position, and the power settings.

b. STALLING SPEEDS.

(1) CLEAN CONDITION (FLOATS UP — GEAR UP) GROSS WEIGHT 27,000 LBS.

(a) With cowl flaps a quarter open and power on, the indicated stalling speed is approximately 53 knots, with a sinking rate of 300 ft/min.

(b) With cowl flaps a quarter open and power off, the indicated stalling speed is approximately 55 knots with a sinking rate of 300 to 400 ft/min.

The pilot must overcome any tendency to pull nose up before sufficient air speed has been obtained. Below is a table of stalling speeds, with power on, for various load conditions:

Gross Wt. Lbs.	Approximate Minimum Stalling Speed	Approximate Minimum Stalling Speed
	(Floats and Gear Up) Knots	(Floats and Gear Down) Knots
23,000	49	51
27,000	53	55
34,000	60	63

(2) DIRTY CONDITION (FLOATS DOWN—GEAR DOWN).

(a) With cowl flaps a quarter open and power off, the indicated stalling speed is approximately 58 knots with a sinking rate of 400 ft/min.

(b) With cowl flaps a quarter open and power on, the indicated stalling speed is approximately 55 knots, with a sinking rate of 300 ft/min.

In general, the stalling characteristics are very good and require very little effort on the pilot's part during the stall and during recovery. Stalling speeds vary directly with the gross weight of the airplane.

15. SPINS.

This airplane shows no tendency to spin from a slow or steeply banked turn.

When one engine is inoperative, too short a turn toward the dead engine provokes a spin.

If a spin has not progressed too far, recovery may be assisted by increasing power of the engine on the inside of the turn and decreasing power of the engine on the outside of the turn, as well as applying the usual nose-down and opposite aileron and rudder controls. In recovery from a spin, there must be no abrupt movement of the controls.

16. ACROBATICS.

All acrobatics are prohibited in this type of airplane.

17. DIVING.

With a gross weight of 27,000 pounds, airplane must not be pulled out at more than three g's.

Maximum engine overspeed is 3060 rpm for 30 seconds.

Place mixture control in "AUTOMATIC RICH" before diving.

Close cowl flaps to prevent too rapid cooling of the engines.

Control trim should be maintained with the idea of keeping tail surface forces to a minimum. Trim the airplane to be slightly nose-heavy in dive, rather than tail-heavy. If airplane were trimmed tail-heavy, there would be an inherent tendency to pull up. This condition might lead to pulling up the elevator too suddenly.

Air loads build up rapidly on a large airplane. For this reason, any abrupt movement of the controls should be avoided.




Figure 29—Interior Lights Diagram

NOTE.—THE LIMITATIONS AND RESTRICTIONS ON THIS AIRPLANE ARE SUBJECT TO CHANGE AND THE LATEST SERVICE INSTRUCTIONS AND APPLICABLE TECHNICAL ORDERS MUST BE CONSULTED.

18. NIGHT FLYING.

(See figures 29 and 30.)

Night landings on water should be made with power sufficient to avoid a pancake landing in case altitude is misjudged.

Projector lights are provided for night flying, as well as fluorescent and filament lights, and blackout curtains. Projector lights are located in the three forward compartments. Fluorescent lights are located in the bomber's and pilot's compartments. The usual compartment lights and extension light receptacles are also provided.

Exterior lights include running, tail, formation, recognition, section, landing, and anchor lights.

CAUTION

When the airplane is not in motion, if landing lights are operated more than five seconds, they will overheat and must be replaced.

Also included in the airplane is the AN/APN-4 and AN/ARN-8 navigational equipment.

Signal equipment includes a signal flare pistol, firing tube, and ammunition containers.

19. APPROACH AND LANDING.

a. **GENERAL.**—Best landing approach speed depends on such factors as loading, altitude, and position of landing gear or floats. (Reference should be made to Section II, paragraph 14.)

Pilot should check to see that his rate of descent is not too rapid, slowing it when necessary by increasing power and nosing up within safe indicated air speed limits.

Sufficient speed above stalling speed should be maintained to insure maneuverability, particularly under bad visibility conditions. Set propeller for take-off rpm (low pitch).

When flying a heavy airplane it should be remembered that a body tends to maintain motion in a straight path; therefore, if a steep glide is being made with accompanying high rate of descent, it takes time and a considerable force to flare out this rate of descent and change the motion to one parallel to the ground. With a rate of descent of over 500 feet per minute, it cannot reasonably be expected to start the flare five to ten feet above the ground and make a soft landing.

It is desirable to have the cowl flaps closed during glides to prevent rapid cooling of the engines; however, a one-third open cowl flap position may be desirable during the final approach if there is a possibility of high power suddenly being needed to continue flight.

During long glides at part or closed throttle, when low air temperatures prevail, occasional operation of the propeller and throttle controls is recommended in order to prevent congealing of the oil in the propeller cylinder. This operation is recommended because a pitch change introduces hot oil into the cylinder.

b. **LANDING ON LAND.**—The airplane shows no tendency to ground loop in a cross wind, but any drift should be taken out before making ground contact.

Maximum speed at which landing gear should be lowered is 120 knots.

Landing on a smooth, prepared runway is permissible with gross weights up to 34,000 pounds. Lighter weights down to 26,000 pounds are recommended when landing on less favorable terrain under normal conditions.

Landings should ordinarily be made on the main wheels, with the nose wheel held off. After contact, the nose wheel should be held where it is until some speed is lost before easing it down to the runway. This procedure tends to keep the airplane in a high drag attitude as long as possible and to reduce the amount of braking required. However, the tail should not be held down until all control is lost, as this practice will result in dropping the nose violently. For the same reason, brakes should not be applied until all three wheels are on the ground, and the airplane has slowed as much as possible.

CAUTION

Care must be taken not to rock the airplane back on its keel during landing.

c. **LANDING ON WATER.**—When landing on rough water, a stall landing should be made. Night landings, however, should be made with power to avoid a pancake landing in case altitude is misjudged.

Maximum speed at which floats should be lowered is 120 knots.

The airplane has a tendency to porpoise if landed at slow speeds. Minimum speeds should be observed. However, if the airplane is landed at an excessive speed, the nose will come up out of the water.

Maximum gross weight recommended for rough water landing is 27,300 pounds; for smooth water, 34,000 pounds. At gross weights in excess of 30,000 pounds the limiting weight which may be landed safely depends on hydrodynamic considerations.

d. TAKE-OFF PROCEDURE IF LANDING NOT COMPLETED.

- (1) Set props in high rpm position.
- (2) Advance throttle.
- (3) Trim ship for take-off.
- (4) Open cowl flaps.

e. PROCEDURE IF ENGINE FAILS ON LANDING.

(Refer to Section IV, paragraph 5.)




Figure 30—Exterior Lights Diagram

f. BEFORE LANDING ON LAND.

PILOT

- (1) Signal crew to prepare for landing.
- (2) Move landing indicator switch to "INDICATOR LIGHT."
- (3) Lower landing gear.
- (5) Check "FLOATS UP."
- (6) Trim ship for landing.
- (7) Set propellers for 2450-2550 rpm.
- (8) Signal Engineer to shift to "AUTOMATIC RICH."

FLIGHT ENGINEER

- (4) Make visual and manual check to be sure gear is down.
- (9) MIXTURE CONTROL.—Set for "AUTOMATIC RICH."
- (10) Cowl Flaps should be closed.
- (11) CARBURETOR AIR CONTROL.—Set for "DIRECT" except when ice and sleet conditions require "ALTERNATE" setting.
- (12) Open cowl flaps immediately after landing.

g. BEFORE LANDING ON WATER.

- (1) Signal crew to prepare for landing.
- (2) Signal "FLOATS DOWN."
- (4) Check to see if landing gear is up and locked by moving indicator switch to "INDICATE."
- (5) Trim ship for landing.
- (6) Set propellers for 2450-2550 rpm.
- (7) Signal engineer to shift to "AUTOMATIC RICH."

- (3) Lower floats.

- (8) MIXTURE CONTROL.—Set for "AUTOMATIC RICH."
- (9) Cowl flaps should be closed.
- (10) CARBURETOR AIR CONTROL.—Set for "DIRECT" except when ice and sleet conditions require "ALTERNATE" setting.

- (11) Check anti-icer switches "OFF" and signal engineer to turn off tail anti-icer.

- (12) Turn off tail anti-icer and close air scoop dampers for central heater and tail heater. See that all hatches and openings are closed and that bomber's window cover is in position.
- (13) Second mechanic should stand by sea anchor after landing.
- (14) Open cowl flaps immediately after landing.

20. STOPPING ENGINES.

- a. Cowl flaps should be opened. Cylinder temperature should not exceed 200°C (392°F) before stopping, if practicable.

PILOT

FLIGHT ENGINEER

b. Throttles should be opened to 1000 rpm. (Cut switches if necessary when coming up to buoy or beach.)

c. Set propeller control in low pitch ("HIGH RPM").

d. Signal engineer to stop engines.

f. Cut switches after engines stop.

g. Signal "SECURE" after plane is beached or secured to buoy.

h. Instruct radio operator to secure lights and interphones.

i. Place landing gear indicator switch in center position.

j. Put on rudder locks and control yoke locks.

k. Install battens on control surfaces.

e. Put mixture control in "IDLE CUT-OFF" position.

Note

STOPPING AUXILIARY POWER UNIT

Except in an emergency, the auxiliary power unit should always be stopped by shutting off the fuel supply, rather than by turning off the ignition switches.

**21. BEFORE LEAVING THE
PILOT'S COMPARTMENT.**

Check to see that cowl flaps are open.

Check to see that ignition switches are both off.

Check to see that propellers are left in high rpm (low pitch).

Check with engineer to see that mixture control is in "IDLE CUT-OFF" and that fuel selector valves are off.

Lock the controls by the following procedure: First remove control lock from stowage and place aft end in socket located on forward face of bulkhead 2, just outboard of the pilot's seat. Move control yoke to neutral position so that pins at forward end of control

lock fall into holes in the control yoke. These holes are located on either side of the pilot's control wheel on the top surface of the yoke.

To release rudder lock pull latch which is located approximately at the center of the rudder lock handle and move handle aft until it is approximately adjacent to the side of the airplane. The rudder lock is located to the left of the pilot, against the side of the airplane and is marked "RUDDER LOCK." (See figure 23.)

Check to see that automatic pilot is off.

If on land, set parking brakes after waiting for brakes to cool to normal temperature. Parking brakes are located to the right of the copilot. To set the brake, press down brake pedals and pull handle down.

Turn out lights.

★

★

★

AIRPLANE MODELS

SPECIFIC ENGINE
FLIGHT CHART

ENGINE MODELS

PBV-6A

PRATT & WHITNEY
R-1830-92

CONDITION	FUEL PRESSURE (LB./SQ. IN.)	OIL PRESSURE (LB./SQ. IN.)	OIL TEMP.		CYLINDER TEMP.		MAX. PERMISSIBLE DIVING RPM: 3060 (40 SECONDS)					
			°C	°F	°C	°F						
DESIRED	17	8.5	65	149			ALLOWABLE OIL CONSUMPTION					
MAXIMUM	18	100	100	212			NORMAL RATED (MAX. CONT.) U.S. Q.T./HR. IMP. PT./HR.					
MINIMUM	16	65	40	104			MIN. SPECIFIC U.S. Q.T./HR. IMP. PT./HR.					
IDLING	11	15	40	104			MIN. SPECIFIC U.S. Q.T./HR. IMP. PT./HR.					
SUPERCHARGER TYPE: SINGLE STAGE-SINGLE SPEED BLOWER TYPE FUEL GRADE: 100/130, AN-F-28												
OPERATING CONDITION	RPM	MANIFOLD PRESSURE (BOOST)	HORSE POWER	CRITICAL ALTITUDE		USE LOW BLOWER BELOW	MIXTURE CONTROL POSITION	FUEL FLOW (GAL./HR./ENG.)	MAXIMUM CYL. TEMP.		MAXIMUM DURATION (MINUTES)	
				WITH RAIN	NO RAIN				°C	°F		
TAKE-OFF	2700	4.6	1200	S.L.	S.L.		AR	150	116	260	500	5
WAR EMERGENCY												
MILITARY	2700	4.5**	1200	S.L. TO 4800	4800		AR	150	118	260	500	5
NORMAL RATED (MAX. CONT.)	2550	39.5	1050	S.L. TO 7500	7000		AR	114	95	260	500	60
MAXIMUM CRUISE	2170	30.5	700	S.L. 15,000	10200		AL	60	50	232	450	CONTINUOUS
MINIMUM SPECIFIC CONSUMPTION	1750*	31*	560	S.L.	6600		AL	37	31	232	450	CONTINUOUS

REMARKS: * This representative power setting will give best engine economy at 140 psi boost, but not necessarily best miles per gallon.
 ** Limit at 4800 feet. Reduce manifold pressure proportionately with increasing altitude from 48° Hg. at S.L. to 46° Hg. at 4800 feet. Manifold pressures listed are limits at no-ran critical altitudes.

Figure 31—Specific Engine Flight Chart



SECTION III FLIGHT OPERATING DATA

1. ENGINE PERFORMANCE RATINGS.

(See figure 31.)

In general, the ratings of the engine have been established as near the high limits as possible. The engine ratings are limited or bounded by three main criteria; brake horsepower, brake mean effective pressure, and speed. These ratings as set forth in the engine specification may be defined as follows:

a. TAKE-OFF RATING.—This is the maximum power and engine speed permissible for take-off. It should not be maintained longer than necessary to clear obstructions, after which the power should be reduced to normal rated power or less.

b. MILITARY RATING.—This is the maximum power permitted with less regard for long life of the engine than for immediate tactical needs. Military rating, comparable to Take-Off Power with manifold pressures modified to suit altitude conditions, may be used for five minutes.

c. NORMAL RATING (Maximum Continuous).—This is frequently referred to as either "Normal Maximum Rating" or "Maximum-Except Take-Off Power." This is the maximum power at which an engine may be operated continuously for emergency (such as single engine) or high performance operation in climb or level flight. This rating is considered 100 per cent power and speed as a basis from which other operating conditions are calculated.

d. MAXIMUM CRUISE RATING.—This rating limits both the maximum power and maximum rpm permissible for continuous operation with the mixture control in "AUTOMATIC LEAN." The Specific Engine Flight Chart shows the maximum rpm at which the maximum cruising bmep may be maintained.

e. MINIMUM SPECIFIC CONSUMPTION.—Under most conditions of cruising operation, it is neither necessary nor desirable to use the maximum cruising power available from the engine. In such instances maximum engine efficiency and, as a rule, propeller efficiency is attained by maintaining the maximum permissible cruising torque or brake mean effective pressure as set forth on the bmep Cruising Chart. (See figure 64.) Other power and speed combinations may be selected from the Engine Operating Limits Curve and lower values may be extrapolated. (See figure 66.)

2. AIR SPEED LIMITATIONS.

(These limitations and restrictions are subject to change, and the latest service instructions and applicable technical orders must be consulted.)

a. MAXIMUM SPEEDS AND ACCELERATIONS.—Restricted speeds for gross weights in excess of 26,000 pounds are given in the table below. The restricted speed for any load in extremely rough air is 110 knots.

Gross Weight (Pounds)	Permissible Accelerations		Permissible Speed (Knots—Indicated)
	(Positive)	(Negative)	
26,000	3.2 g	1.6 g	190
28,000	2.9 g	1.5 g	175
30,000	2.7 g	1.4 g	165
32,000	2.5 g	1.3 g	155
34,000	2.3 g	1.2 g	145




Figure 32—Air Speed Correction Chart

In unusually rough air the permissible speeds listed above are further progressively reduced according to the degree of turbulence. Under extremely adverse conditions a speed range of 100 to 110 knots is recommended. This is considered to be the most favorable range for extremely rough air, based on control and strength limitations.

In addition to the above restrictions on acceleration and speed, increasing care in methods of operations is considered essential at the higher gross weights. Turns should be more moderate and all control movements should be smoother than when operating at lower gross weights.

The maximum recommended gross weights for take-off and landing are:

- Operations from rough water and ordinary fields 27,300 pounds
- Operations from smooth water and smooth prepared runways 34,000 pounds

Take-off from smooth prepared runways with jettisonable load of approximately 2000 pounds 36,400 pounds

Floats should not be lowered at indicated speeds greater than 120 knots.

Landing gear should not be lowered at speeds greater than 120 knots.

b. MINIMUM SPEEDS.—Do not operate the automatic pilot at indicated air speed of less than 85 knots.


For stalling speed at various gross weights see Section II, paragraph 14.

3. AIR SPEED CALIBRATION CHART.

(See figure 32.)

4. BALANCE COMPUTER DESIGNATION.

The balance computer used on this airplane is known as the "LOAD ADJUSTER" and is used with the AN 01-1B-40 weight handbook.



SECTION IV EMERGENCY OPERATING INSTRUCTIONS

1. EMERGENCY OPERATION OF LANDING GEAR.

(See figures 33 and 34.)

a. If gear fails to lower when handle is pushed down, check hydraulic pressure gage. If gage shows over 1000 pounds pressure, return handle to "UP" position and repeat attempt to lower gear. If gear does not lower on second attempt, leave gear handle locked in "DOWN" position and:

b. Release the main wheel up-locks by pulling out the "Tee" handles at the main wheel wells and turning handles a quarter turn.

c. Work gear down by rocking the airplane approximately 14° to each side.

d. Use the emergency "DOWN-LATCH" lever to straighten out the main support struts and latch the gear in the down position. To do this, first insert emergency "DOWN-LATCH" lever through access door provided in side of wheel well, and engage the handle end of the lever over the bolt provided on the auxiliary keel. With the handle end of lever supported by the bolt, guide the outboard end of the lever into the strut socket located just above the pivot point in the strut.

e. Push firmly on the lever to straighten out the strut and the gear will latch down. Repeat the same operation for gear on opposite side.

f. Unlock nose wheel doors by pushing door lock handle aft, thus releasing the door lock pins. The door lock handle is located on the starboard side, forward of bulkhead 1.

g. Insert hydraulic hand pump handle or emergency "DOWN-LATCH" lever handle in the aft end of the starboard door torque tube, located aft of bulkhead 2, and push inboard counterclockwise. This rotates the torque tube and thus opens the nose wheel well doors.

h. Lock torque tube in "DOORS OPEN" position by swinging locking link inboard over the lug on the torque tube end fitting. Insert locking pin and retain with safety pin.

i. Remove the aft cover plug of the nose wheel and insert emergency lever through the hole. Strike the end of the up-latch sharply to unlatch the nose gear.

j. Attach the emergency lever to the torque tube between the packing nut and the jack fitting, so that the ratchet pawl fits into the teeth of the jack fitting. Using the lever as a ratchet, force the gear into the down position. To lock, use a slow, heavy push.

k. Remove the forward plug of the wheel well cover to examine the down-latch, and use emergency "DOWN-LATCH" lever to determine if the down-latch is locked. If it is locked, the red collar on the lever will not extend above the hole in the cover, and the oleo strut will be vertical and against the down bumper.

CAUTION

Before operating gear again, be sure to release the emergency door lock pin.

If the landing gear failure is due to failure of starboard engine or engine driven hydraulic pump, and not to loss of fluid caused by leaking reservoir or lines, the gear may be lowered with pressure supplied by the hand pump. Latch control handle in "DOWN" position before operating pump. Be sure to check "LANDING GEAR WARNING" indicator lights. To raise gear latch control handle in "UP" position and operate hand pump as described above.

2. EMERGENCY OPERATION OF FLOATS.

(See figures 35 and 36.)


a. TO LOWER FLOATS:

(1) Remove hand crank from stowage on starboard side of bulkhead 4 below engineer's seat.


(2) Engage crank in socket marked "FAST" and crank counterclockwise. The socket is located in center of bulkhead below engineer's seat.

b. TO RAISE FLOATS:


(1) Insert crank in socket marked "FAST" and turn clockwise until load gets too heavy to operate easily.




- 2** OPEN HATCH ON INSIDE WALL OF WHEEL WELL



- 3** PULL UP-LOCK EMERGENCY RELEASE AT THE SAME TIME PUSH STRUT OUTWARD CAUSING GEAR TO FALL OUTB'D (MAY BE ACCOMPLISHED BY ROCKING SHIP)



- 1** SET SELECTOR VALVE AT "DOWN" POSITION



- 4** ATTACH HAND-LEVER AS SHOWN, BAR "B" PASSING THROUGH HATCH AND ENGAGING SOCKET IN MAIN STRUT. PUSH STRUT OUTB'D INTO LOCKED POSITION.




Figure 33—Emergency Lowering of Main Landing Gear




Figure 34—Emergency Lowering of Nose Gear




Figure 35—Float Crank Ready to Operate




Figure 36—Float Crank in Stowed Position

(2) To raise floats the remainder of the distance, move crank to "SLOW" socket and continue to turn clockwise until floats are latched in the up position.

3. EMERGENCY TAKE-OFF.

If oil was diluted when engines were last stopped, take-off may be made as soon as pressure is steady at around 65 to 75 pounds.

If oil was not diluted, after starting engines, the oil dilution valve may be opened intermittently at intervals of a few seconds for a period of about 15 seconds, or until oil pressure is constant.

Be sure propellers are in highest rpm (full low pitch) position.

Leave cowl flaps open. Closing cowl flaps will not assist warm-up and will damage engine.

Proceed with normal take-off.

4. ENGINE FAILURE DURING TAKE-OFF.

In case of engine failure at a low air speed and/or a low altitude, the pilot must immediately choose between throttling the remaining engine and landing straight ahead (if the ground or water is suitable); or retracting landing gear or floats, carefully building up speed, and continuing in flight until a safe landing can be effected.

If decision is made to land, less damage will probably result if the landing gear is retracted, unless there is a perfect field ahead.

If the landing is to be made on good terrain, but in a limited space, the airplane should be stalled in; then brought promptly to the three-point attitude and brakes

applied. Landings of this type can be made most successfully if tires and brakes are in good condition.

If continued flight is undertaken, each maneuver should be made as gently as possible, to avoid an attitude from which recovery is impossible.

When it is necessary to obtain altitude immediately, landing gear or floats should be retracted; however, since the hydraulic pump is located on the starboard engine, failure of that engine will make retraction of the landing gear impossible except by emergency methods requiring approximately five minutes. (See Section IV, paragraph 1.) Floats are controlled electrically, so that failure of an engine will not affect their operation. Time required to retract the floats is 20 seconds.

The airplane must be trimmed (rudder tab first, aileron tab second) for as good a "hands off" condition as possible.

Banks must be made with the dead engine high, and only shallow banks should be attempted.

Feather the useless propeller to reduce the drag. If propeller cannot be feathered, place it in low rpm position to reduce vibration. Sufficient air speed will cause the propeller to windmill and turn the dead engine over fast.

Leave propeller of the useful engine in the high rpm position to give maximum engine power output. Shut off the fuel to the useless engine with the fuel selector valve as soon as practicable. The use of more than rated power at any altitude must be kept to a minimum to avoid overheating and detonation which will result in damage to, if not complete failure of, the remaining

engine. The use of a rich mixture will help slightly to keep engine cylinder temperatures down.

When landing, rapid settling of the airplane must be anticipated, particularly at the time that landing gear or floats are lowered. Before landing is attempted, the pilot should gain all the altitude possible, and where practical, simulate landing procedure by lowering wheels or floats and reducing power. Lowering of the wheels by use of the emergency hand pump will require approximately three minutes. (See Section IV, paragraph 1.)

5. ENGINE FAILURE DURING LANDING.

If engines fail on landing, the procedure recommended is as follows:

Take care not to lose air speed.

Trim rudder and aileron tabs. "HANDS-OFF" trim, if possible.

Place the propeller in the low rpm position, if possible.

Feather the useless propeller as soon as possible. If propeller cannot be feathered it should be allowed to windmill in the low rpm position.

Shut off fuel to the dead engine, and shut off the fuel selector valve as soon as practical.

Place the propeller of the good engine in high rpm position if power is needed to reach the landing spot. (Do not exceed maximum permissible engine overspeed of 3,060 rpm for 30 seconds.)

Rapid settling of the airplane must be anticipated.

If the landing gear or floats have not been lowered at the time of engine failure, considerable loss of altitude may be expected when they are lowered. If the starboard engine fails, the hydraulic system pump will be inoperative, and landing gear must be lowered by emergency methods requiring approximately three minutes. (See Section IV, paragraph 1.) If conditions permit, altitude should be attained and a few landings simulated at a safe altitude.

6. MISCELLANEOUS EMERGENCY MEASURES.

a. EMERGENCY LANDING ON LAND — WHEELS UP.—In the event the landing gear fails to lower prior to landing and cannot be lowered by emergency means, a normal power-on landing should be made.

If landing is to be attempted on clear terrain, floats should be lowered.

If landing on terrain where any obstructions exist, such as brush or trees, floats should be up.

b. EMERGENCY ESCAPE HATCHES. (See figure 37.)—The only safe escape available in flight is through the waist gun blisters or the tunnel gun hatch. The only other escapes are through the bow turret manhole, the pilot's compartment hatch and the navigator's hatch, but are only suitable for use on the water.

c. DITCHING.—No ditching procedure has been established for this airplane. Crew members should remain at their respective stations until landing is effected.

d. LIFE RAFT.—A Mark VII, Type D, seven man life raft is stowed on the forward face of bulkhead 7 on the port side. It is held in place by two straps with quick release buckles. (See figure 37.)

To remove the life raft for use:

- (1) Unbuckle the two retaining straps.
- (2) Pull the rip cord. This action should open the CO₂ gas container and automatically inflate the life raft.

CAUTION

If the life raft fails to inflate automatically on pulling the rip cord, the CO₂ containers must be opened manually.

(3) Throw the complete assembly quickly through the blister opening.

Emergency provisions and equipment are contained in the life raft. A snubbing rope is attached to the structure of the airplane and to the life raft to prevent it from drifting away. After the raft is occupied, the snubbing rope should be released as soon as possible.

e. FIRE EXTINGUISHERS. (See figure 37.)—Four CO₂ shatterproof type fire extinguishers are located in the airplane.

(1) One five pound capacity portable fire extinguisher is located on the port forward side of bulkhead 4.

(2) One two pound capacity hand fire extinguisher is located on the starboard aft side of bulkhead 2.

(3) One two pound capacity hand fire extinguisher is located on the face of starboard shear web, between bulkheads 4 and 5.

(4) One two pound capacity hand fire extinguisher is located on aft face of bulkhead 6 below watertight door at center of ship.

Note

Full instructions for use and maintenance are written on each fire extinguisher.

f. LIFE JACKETS AND PARACHUTES.


(See figure 37.)

(1) LIFE JACKETS.—Eight life jackets are located in the airplane at the following positions:


(a) Two on the forward port face of bulkhead 6.

(b) One on the aft face of bulkhead 4 at the center of the airplane below the watertight door.

(c) Two on the forward starboard face of bulkhead 2 behind the copilot's seat.



Emergency Equipment Locations



Emergency Escape Routes

Figure 37—Emergency Equipment and Escape Routes

(d) One on the bottom of the airplane forward of bulkhead 4 on the starboard side.

(e) One on the forward side of the aft food locker, which is on the forward starboard side of bulkhead 5.

(f) One attached to the door of the radio operator's locker, located forward of bulkhead 4.

(2) PARACHUTES.—Eight parachutes are located in the airplane at the following positions:

(a) Two on forward face of bulkhead 6 near the floor; one on the port and one on the starboard side.

(b) One between bulkheads 4 and 5 on shear web, starboard side, near the top.

(c) One on forward face of bulkhead 4 at center line of ship below watertight door.

(d) One forward of beltframe 3.0 on port side at top of airplane.

(e) Two on the aft face of bulkhead 2 at center of ship; one is above the watertight bulkhead door and one below.

(f) One on the forward inboard edge of the navigator's table.

(3) ASSIGNMENT OF LIFE JACKETS AND PARACHUTES.—Each member of the crew should be assigned a certain life jacket and parachute, and shown their locations before flight, to prevent confusion in case of emergency.

g. FIRST AID KIT.—The first aid kit is located on the upper forward port side of bulkhead 6. Complete instructions for use of contents are contained inside the kit. Check to see that the seal on the kit has not been broken.

h. BILGE AND REFUELING PUMP. (See figure 38.)—A combination bilge and refueling pump is stowed on the hull bottom between beltframe 5.75 and bulkhead 6, on the starboard side of the ship. The unit consists of two pumps (one for fuel and one for bilge water) and an electric motor.

(1) To operate as a refueling unit proceed as follows:

(a) Remove unit from its stowage and plug electrical cable into any convenient utility receptacle.

(b) Attach fuel hose (nozzle section) to fuel pump outlet. The fuel pump is located by an arrow on control housing. Attach second length of fuel hose to fuel pump inlet.

(c) Pull control handle out and over to refueling pump side.

(d) With pump and hose in refueling position, start pump by moving push rod switch, located at the base of the electric lead-in box, to "ON" position.

(2) To use the unit as a bilge pump proceed as follows:

(a) Remove unit from its stowage and plug electrical cable into any convenient utility receptacle.




Figure 38—Bilge and Refueling Pump

(b) Attach water hose to bilge pump outlet. The bilge pump is located by an arrow on control housing. Attach second length of water hose to bilge pump inlet.

(c) Cock control handle toward bilge pump before starting motor.

(d) With pump and hose in bilging position, start pump by moving push rod switch, located at the base of the electric lead-in box, to "ON" position.

Capacity of refueling pump is 1500 gallons per hour, and of bilge pump is 840 gallons per hour.

★

★





Figure 39—Diluter—Demand Oxygen Equipment—Portable Type



SECTION V OPERATIONAL EQUIPMENT

1. REMOTE COMPARTMENTS.

- a. Bomber's Compartment.
- b. Engineer's Compartment.
- c. Controls in Radio Operator-Navigator's Compartment.
- d. Crew's Quarters.
- e. Waist Gun Compartment.
- f. Tail Compartment.

2. OPERATION OF OXYGEN EQUIPMENT.

(See figure 39.)

This airplane carries two portable individual supply type diluter-demand oxygen units, which have their own integral supply system, oxygen regulators and flow indicators. Mountings for these units are placed at the pilot's, co-pilot's and engineer's stations. The units may be carried to the various parts of the airplane as required.

CHECK LIST

This check list is to be used prior to take-off whenever there may be a possibility of flight to oxygen altitudes.

- a. Close emergency valve.
- b. Open cylinder valve, allowing at least 10 seconds for pressure in line to equalize. Pressure gage should read 1800 ± 50 pounds per square inch if the cylinder is fully charged.
- c. Close cylinder valve. After a few minutes, observe pressure gage and simultaneously open cylinder valve. If gage pointer jumps, leakage is indicated.
- d. If leakage is indicated, test further. Open cylinder valve, carefully noting pressure gage reading, then close cylinder valve. If gage pointer drops more than 100 pounds per square inch in five minutes, there is excessive leakage and the unit must be repaired prior to use.
- e. Check mask fit by placing thumb over end of mask tube and inhale lightly. If there is no leakage, mask will adhere tightly to face due to suction created. If mask leaks, tighten mask suspension straps and adjust nose wire.

WARNING

Do not use mask that leaks.

- f. Couple mask securely to breathing tube by means of quick-disconnect coupling.

CAUTION

Mating parts of coupling must be fully engaged, and not "cocked."

- g. Open cylinder valve. Depress diaphragm knob through hole in center of regulator case, and feel flow of oxygen into the mask; then release diaphragm knob. Breathe several times, observing oxygen flow indicator for "blink", verifying the positive flow of oxygen.

Note

Since the amount of added oxygen is very small at sea level, the oxygen flow indicator may not operate while the plane is on the ground. In this case, turn air-valve to "OFF" or to "ONE-HUNDRED PER CENT OXYGEN", and test again. If oxygen flow indicator operation is now satisfactory, re-set air-valve to "ON" or "NORMAL OXYGEN", in which setting adequate oxygen flow and "blinker" operation will be assured at oxygen use altitudes.

- h. Check emergency valve by turning counterclockwise slowly until oxygen flows vigorously into mask, then close emergency valve.

OPERATING INSTRUCTIONS


Oxygen shall be used at all flights above 10,000 feet and on night flights above 5,000 feet (except by personnel whose keenness of night vision is not essential). On flights of more than four hours between 8,000 and 10,000 feet, oxygen should be used at least 15 minutes out of each hour.

- a. Open oxygen cylinder valve. Pressure gage should read $1,800 \pm 50$ pounds per square inch if cylinder is fully charged.

CAUTION

If cylinder is not fully charged, replace with a new cylinder and re-check.

- b. Set regulator air-valve to "ON" or "NORMAL OXYGEN" except when presence of excessive carbon

RESTRICTED
AN 01-5MC-1

- R RADAR
 1 NAV INTERPHONE STA BOX AIA-2
 2 VISUAL INDICATOR
 3 MARKER BEACON RECVR, ARN-B
 4 XMTR CONTROL ARC-5
 5 RECVR CONTROL ARC-5
 7 RADIO CONTROL SCR-269
 8 PILOT'S HF & LF RECVRS ARC-5

- 10 ANTENNA RELAY ARC-5
 11 RECVR VHF ARC-5
 12 XMTR VHF ARC-5
 13 XMTR HF ARC-5
 14 DISTRIBUTION BOX AIA-2
 15 JUNCTION BOX AIA-2
 16 JUNCTION BOX SCR-269
 17 RADAR OPS' STA. BOX AIA-2
 18 TRAILING ANTENNA SPOOL
 19 RECVRS. RAX-1
 20 JUNCTION BOX RAX-1
 21 VOLTAGE REGULATORS
 22 MAIN DISTRIBUTION PANEL
 23 RADIO OPS' POWER & SWITCH BOX
 24 FREQUENCY INDICATOR LM-14

- 25 RADIO CONTROL UNIT SCR-269
 26 CONDENSER BOXES TYPE "A"
 27 DYNAMOTOR AIA-2
 28 DYNAMOTOR RL-24-C
 29 ELECTRIC STOVE
 30 DYNAMOTOR ART-13
 31 ALTERNATOR
 32 INVERTOR SCR-269
 33 RECVR HF ARC-5
 34 RECVR CONTROL ARC-5
 35 XMTR KEY ART-13
 36 RADIO OPS' CONTROL BOX AIA-2
 37 INTERPHONE BOX ARC-5

- 38 ANTENNA SHUNT CAPACITOR
 39 INTERPHONE AMPLIFIER RL-24-C
 40 XMTR ART-13
 41 ANTENNA LOADING COIL ART-13
 42 MODULATOR UNIT ARC-5
 43 PILOT'S RADIO POWER BOX

Figure 40—Radio Equipment in Radio Operator's Compartment

monoxide is suspected, then set to "OFF" or "100 PER CENT OXYGEN."

c. Put on oxygen mask and couple securely to breathing tube by means of quick-disconnect coupling.

CAUTION

Be sure that quick-disconnect coupling is fully engaged.

d. Check mask fit as outlined in "Check List" by squeezing mask tube.

CAUTION

Never check mask fit by squeezing mask tube while Emergency Valve is "ON."

e. Depress diaphragm knob through hole in center of regulator case and feel flow of oxygen into mask; then release diaphragm knob. Breathe several times, observing oxygen flow indicator (if installed) for "blink," which verifies the positive flow of oxygen.

Note

Do not use oxygen supply below 300 pounds per square inch, except in an emergency.

f. Upon completion of oxygen usage, close cylinder valve.

WARNING

Use emergency valve only if regulator becomes inoperative or anoxia is suspected.

3. OPERATION OF COMMUNICATION EQUIPMENT.

a. GENERAL PLAN.

(1) CONSTITUENTS.—The communication and navigational equipment consist of the following units:

(a) AN/ARC-5 command receivers and transmitters for intersquadron and short range communication.

(b) The RAX-1 liaison receivers and the ART-13 liaison transmitter for intersquadron and long range communication.

(c) The RL-24C interphone amplifier and the AN/AIA-2 interphone distribution system.

(d) The AN/ARN-8, AN/APN-4, SCR-269F, and AN/APN-1 navigational equipment.

(e) The LM-14 frequency meter.

(f) Provisions have been made for the following types of radar equipment: AN/APX-2, AN/APS-3, and ABA-1 as an alternate for AN/APX-2.

(2) LOCATIONS.

(See figures 40 and 41.)

AN/ARC-5 COMMAND EQUIPMENT

EQUIPMENT

19 to 9.1 Megacycle Receivers

2.1 to 9.1 Megacycle Transmitters

Very High Frequency (V.H.F.) Transmitter and Receiver.

LOCATION

One (.19-.55) megacycle receiver and one (3-6) megacycle receiver located on the aft starboard side of bulkhead 2 over radar operator's rack. Both are located on the forward part of the rack.

One (3-6) megacycle receiver located outboard of the interphone amplifier on lower portion of radio operator's rack.

Three additional (.19-.55), (1.3-3), and (6-9.1) megacycle receivers stowed on rack on top of the food locker, which is forward of bulkhead 5 on the starboard side of the airplane.

One (3-4) megacycle transmitter located on top and outboard part of the radar operator's rack.

Four additional (2.1-3), (4-5.3), (5.3-7), and (7-9.1) megacycle transmitters stowed aft of bulkhead 4 under the rack which contains the dynamotors.

Located on top of the radar operator's rack. The receiver located in inboard position and the transmitter located adjacent to and outboard of the receiver.




Figure 41—Radio Equipment Outside of Radio Operator's Compartment

EQUIPMENT

LOCATION

Transmitter Control Box for V.H.F. and (2.1-9.1) Megacycle Transmitters.

Located on the forward face of bulkhead 2 above the pilot's switch panel and on the center line of the airplane.

Receiver Control Boxes for (.19-9.1) Megacycle Receivers.

Two receiver control boxes located directly over the pilot's seat on the port side of the fast feathering switches.

The control for the receiver on the radio operator's rack is located on the forward face of bulkhead 4 under the main distribution panel and inboard of the radio power junction box.

Modulator and Dynamotor.

On the starboard side between bulkhead 2 and station 2.5 near the skin line and just above the chine.

Antenna Relay Unit.

On the aft side of the channel which hangs from belt-frame 2.5 over the radar operator's station. This channel supports the aft end of the rack which supports the low frequency receivers.

Jack Boxes.

One on the pilot's equipment panel beside the pilot's seat.

One of the copilot's equipment panel beside the copilot's seat.

One below the radio operator's table on the inboard face of the vertical angle which supports the table.

RAX-1 LIAISON RECEIVING EQUIPMENT

Receivers.

On top of the radio operator's rack.

Junction Box.

Outboard of the radio operator's rack between stations 3.33 and 3.66.

AN/ART-13 LIAISON TRANSMITTING EQUIPMENT

Transmitter.

Below RAX-1 liaison receivers on radio operator's rack.

Antenna Loading Coil.

Aft of bulkhead 3 and forward of radio operator's rack.

Antenna Shunt Capacitor.

On lower part of radio operator's rack, between antenna loading coil and station 3.33.

EQUIPMENT

LOCATION

Dynamotor. On aft end of dynamotor rack, which is on starboard side, aft of bulkhead 4.1, inboard of shear web.

RL-24C INTERPHONE AMPLIFIER

Amplifier. On aft part of radio operator's rack, under the ART-13 transmitter.

Dynamotor. Aft of AIA-2 dynamotor, on top of dynamotor rack.

AN/AIA-2 INTERPHONE DISTRIBUTION SYSTEM

Control Boxes. Pilot's—On pilot's equipment panel.
Copilot's—On copilot's equipment panel.
Radio Operator's—Over radio operator's table, forward side of bulkhead 4.

Station Boxes. Bomber's—Starboard and forward of station .33.
Navigator's—Over navigator's table and on lower aft part of rack which supports AN/APN-4 indicator.
Radar Operator's—Lower aft part of radar operator's table, outboard of sliding writing table.
Engineer's—Port side of compartment opposite engineer's seat.
Port Waist Gunner's—Under longeron which runs fore and aft under blister, approximately 12 inches forward of the gun post.
Starboard Waist Gunner's—Same as port waist gunner's only on starboard side.
Tunnel Gunner's—Port side, forward of station 7.5, outboard and slightly aft of flare release tube.

Junction Box. Between station 2.5 and bulkhead 3 on starboard side, forward of radio operator's rack and below the window.

Dynamotor. Top forward position on dynamotor rack.

Interphone Distribution Box. Starboard and forward of bulkhead 3 over radar operator's seat.

AN/ARN-8 NAVIGATIONAL EQUIPMENT

Receiver. Above navigator's visual indicator on the rack aft of bulkhead 2, above navigator's table.

EQUIPMENT

LOCATION

Indicator Light.

Above automatic pilot controls and below and between the manifold pressure gages on pilot's instrument panel.

AN/APN-4 NAVIGATIONAL EQUIPMENT

Receiver.

Port side under navigator's table, just forward of station 2.5.

Visual Indicator.

Over the Navigator's table, under the AN/ARN-8 receiver.

SCR-269F NAVIGATIONAL EQUIPMENT

Receiver.

On top aft section of radio operator's rack, forward of bulkhead 4 and outboard of main distribution panel.

Control Box.

Over the copilot's seat forward of copilot's projector light and outboard of fast feathering switches.

Indicator.

On pilot's instrument panel (on port side) above vacuum control valve.

Junction Box.

Above and outboard of radio operator's rack and aft of station 3.33.

Inverter.

On forward part of dynamotor rack under AIA-2 and RL-24C dynamotors.

AN/APN-1 NAVIGATIONAL EQUIPMENT

Transmitter-Receiver.

Aft of bulkhead 4 on port side of airplane on a bracket built up from bottom of airplane.

EQUIPMENT

LOCATION

Power Junction Box.

Aft side of bulkhead 4 between bulkhead 4 and the transmitter-receiver.

Indicator Lights.

Starboard side of automatic pilot controls on pilot's instrument panel.

Selector Switch.

Starboard side of pilot's instrument panel inboard of landing gear warning lights and between turn and bank indicator and hydraulic pressure gage.

Indicator.

Port side of pilot's instrument panel, outboard and slightly above remote compass indicator; inboard, and above vacuum control valve.

LM-14 FREQUENCY METER


LM-14 Frequency Meter.

On rack forward and outboard of main distribution panel and above radio operator's rack.

Figure 42—

AN/ART-13 Transmitter

1. Dynamotor Reset
2. Transmitter Reset
3. Loading Coil
4. Cone Terminal
5. Antenna Terminal
6. Antenna Receiver
7. Local Remote Switch
8. Test Switch
9. Channel Selector Switch
10. Antenna Ammeter
11. Meter Selector Switch
12. Volt-Ammeter
13. Power Level Switch
14. Emission Selector Switch
15. Side Tone Gain Control
16. Microphone Selector Switch
17. Keylock
18. Side Tone Jacks
19. Microphone Jack
20. Antenna Terminal
21. Antenna Ammeter
22. Transmitter Terminal
23. Control L
24. Control K



b. LIAISON RADIO EQUIPMENT.

(1) OPERATION OF AN/ART-13 TRANSMITTER.

(See figure 42.)

(a) GENERAL.—The model AN/ART-13 transmitting equipment is designed to permit rapid frequency change, incorporating an Autotune system. The Autotune system is an electrically controlled means of mechanically repositioning adjustment elements such as switches, variable inductors and variable capacitors to permit transmission on any one of eleven preset frequencies.

WARNING

Operation of this equipment involves the use of high voltages which are dangerous to life. Operating personnel must at all times observe all safety regulations. Do not change tubes or make adjustments inside equipment with high voltage supply on. Always turn "OFF" the dynamotor or other associated power equipment and open main switch in power supply circuit. Under certain conditions, dangerous potentials may exist in circuits with the power control in the "OFF" position, due to charges retained by capacitors, etc. To avoid casualties, always discharge and ground circuits prior to touching them. Caution should be observed when operating this equipment for test purposes in the vicinity of other receiving or transmitting equipment. Due to the relatively high power output of this equipment, operation in the vicinity of other equipment may cause flashover or arcs in the remote equipment, should the antennae be resonant. Testing should be done at a low power level under this condition.

(b) COMPARISON OF COMMUNICATION BY C. W. (CONTINUOUS WAVE) AND M. C. W. (MODULATED CONTINUOUS WAVE).

1. C. W. TELEGRAPHY.—This method provides the greatest distance range, and gives the least interference, both in the immediate vicinity of the transmitter and at a distance. Since "C. W." requires sharp tuning, it is more difficult when slightly off frequency, to establish initial communication by "C. W." than by "M. C. W."

2. M. C. W. TELEGRAPHY.—This method is most valuable as an auxiliary to "C. W." transmission during conditions of fading. Also, during initial calls and at other times when the transmitting operator is uncertain whether the receiver standing by for him is in oscillating (heterodyne) condition, transmission by "M. C. W." would appear the preferable method. After establishing communication by "M. C. W.," if com-

munication is poor, a shift to "C. W." generally results in improvement. When the emitted carrier lacks frequency stability due to excessive vibration or other causes, the "M. C. W." method may be preferable to "C. W."

(c) DISTANCE-FREQUENCY CHART.—

The following table is based upon general experience with high frequencies and aircraft communication. Communication conditions on these frequencies may show appreciable variation from day to day. For any given distance, the best order of frequency not only varies with the time of day, but is also somewhat lower in the winter time than during the summer. Average frequency ranges for best results over various communication distances are estimated below:

<i>Distance in Miles</i>	<i>Mid-day</i>
0-50	3,000-4,525
50-150	3,000-4,000
150-250	4,000-6,000
250-400	6,000-8,000
400-600	6,000-9,050
600-1,000	8,000-9,050

<i>Dawn or Dusk</i>	<i>Night</i>
3,000-4,525	3,000-4,525
3,000-4,000	3,000-4,000
3,500-4,525	3,000-4,000
4,000-6,000	3,500-4,525
4,500-7,000	4,000-6,000
6,000-8,000	4,500-7,000

(d) OPERATIONAL CHECK.

1. The AN/ART-13 equipment is locally controlled except for remote control of "VOICE" emission.

2. VOICE OPERATION—LOCAL.

a. Place the "LOCAL REMOTE" switches in the "LOCAL" position.

b. Insert the microphone cord plug into the "MICROPHONE" jack of transmitter.

c. Check the microphone switch beneath the tuning chart, to make sure that the circuit is in "CARBON" position.

d. Place the emission selector switch in the "VOICE" position.

e. Select the Autotune channel corresponding to frequency at which the transmission is desired, with the "CHANNEL" selector switch.

f. Place the power level switch in the "OPERATE" position.

g. Check the battery voltage by rotating the metered circuit selector switch to the "BATTERY VOLTAGE" position. Normal voltage is indicated when the needle comes to rest within the solid yellow portion of the scale under "BATTERY."

h. Rotate the metered circuit selector switch to the "POWER AMPLIFIER PLATE" position.

i. Close the "PRESS-TO-TALK" button on the microphone.

j. Check the "P. A. PLATE" current. When the switch is in the "P. A. PLATE" position, the meter reading is the sum of the power amplifier plate and the modulator static plate currents. Therefore, the zero signal "P. A. PLATE" current reading will be slightly higher than when operating with "C. W." emission.

k. If operating on one of the ten high frequency channels, check the antenna current on the left meter of the transmitter panel.

l. If these readings are normal, the transmitter may now be operated with voice emission, the carrier being controlled by the "PRESS-TO-TALK" button on the microphone.

3. VOICE - OPERATION - REMOTE. — When positioning has been completed for "VOICE OPERATION—LOCAL," the system can be operated remotely by flight crew for "VOICE" emission.

a. Insert microphone cord plug into the "MICROPHONE" jack of jack box.

b. Rotate four position selector switch on control box to "LIAISON TRANS." position.

c. Close the "PRESS-TO-TALK" button on the microphone.

4. C. W. OPERATION.

a. Place the "LOCAL-REMOTE" switch in the "LOCAL" position.

b. Insert the telegraph key cord plug in the "KEY" jack.

c. Place the emission selector switch in the "C. W." position.

d. Select the Autotune channel corresponding to the frequency upon which the transmission is desired, using the "CHANNEL" selector switch.

e. Check the voltage by placing the metered circuit selector switch in the "BATTERY VOLTAGE" position. Normal battery voltage is indicated if the needle comes to rest within the solid yellow portion of the scale under "BATTERY."

f. Rotate the meter circuit switch to "P. A. PLATE" position.

g. Close the telegraph key and check the "P. A. PLATE" current. The right meter should indicate the power amplifier plate current within the range of the yellow shaded portion of the scale designated as "C. W."

h. Check the antenna current indicated by the left meter on the transmitter panel.

i. If meters indicate normal operating conditions, operation may be continued with "C. W." emission, using the telegraph key to control the radio frequency output.

5. M. C. W. OPERATION.

a. Place the "LOCAL-REMOTE" switch in the "LOCAL" position.

b. Insert the telegraph key cord plug into the "KEY" jack.

c. Place the emission selector switch in the "M. C. W." position.

d. Select the Autotune channel corresponding to frequency at which the transmission is desired, with the "CHANNEL" selector switch.

e. Check the battery voltage by rotating the metered circuit selector switch to the "BATTERY VOLTAGE" position. Normal battery voltage is indicated if the needle of the right meter comes to rest within the solid yellow portion of the scale under "BATTERY."

f. Rotate the metered circuit switch to the "P. A. PLATE" position. Close the telegraph key to check the plate current.

g. When operating with "M. C. W." emission, the right meter on the transmitter panel indicates both power amplifier and modulator plate current. Therefore, the meter reading will be considerably greater than for "C. W." emission. Normal current is indicated if the meter needle comes to rest within the solid yellow portion of the scale designated as "M. C. W."

h. Check the antenna current as indicated by the left meter on the transmitter panel if operating in one of the ten high frequency channels.

i. If meter readings are normal, operation may be continued with the modulated carrier controlled by the telegraph key.

Note

Thermal-operated overload relays located on the "POWER CONTROL UNIT" are normally closed, and operate to break the primary circuit to the dynamotor when an overload occurs. These relays may be returned to their normal position by pressing the "RESET" buttons.

6. FREQUENCY RANGE—200KC TO 600 KC.

a. Connect approximately 200 ft of trailing wire antenna to "ANTENNA" terminal on antenna loading coil.

b. Set the range switch, control "K," on the loading coil panel. The frequency at which the circuit will tune increases as the control is rotated in a clockwise direction.

Note

If an output frequency in the range 200 KC to 300 KC has been selected, considerable care should be exercised in the setting of the range switch to prevent doubling frequency in the output circuit.

c. Rotate the "EMISSION" selector switch to the "C. W." position, and the channel selector switch to the "L FREQUENCY" position.

d. Place the metered circuit selector switch in the "P.A. PLATE" position.

e. Place the power level switch in "TUNE" position.

f. Operate the "TEST" switch to the "ON" position.

g. Immediately tune control "L" for minimum P.A. current as indicated by right meter on the transmitter panel.

h. Try several positions of control "K" until the position is found that gives the minimum "P.A. PLATE" current.

i. Release the "TEST" switch and place the power level switch in the "OPERATE" position.

j. Place the metered circuit selector switch in the "P.A. GRID" position.

k. Return the "TEST" switch to the "ON" position and check the "P.A. GRID" current. The meter should indicate grid current within the yellow shaded portion of the meter scale under "P.A. GRID."

l. Assuming that normal grid current is flowing, operate the metered circuit selector switch to the "P.A. PLATE" position.

m. Check to make certain that the power amplifier tank circuit is tuned to the point that gives the minimum "P.A. PLATE" current by rotating control "L" about the original setting.

Note

The actual value of "P.A. PLATE" current is of little importance, and will vary considerably with frequency. Do not detune any of the dials to make the meter read in the "C.W." area on the meter scale. The transmitter is operated below maximum loading on some low frequencies in order to reduce flashover troubles in the loading coil at high altitudes.

n. When the proper positions of the controls have been established, lock the variometer, control "L," in position to prevent detuning of the circuit by vibration or shock.

7. SIDE TONE GAIN CONTROL.—With the transmitter in operation, the amount of side tone output delivered to the receiver can be varied to any one of six positions. The control is located beneath the

tuning chart on the transmitter front panel. The chart holder is hinged and may be swung upward if the clamps on the lower edge are released.

8. ANTENNA REQUIREMENTS.—When operating the transmitter in the high frequency band, it is recommended that the "INVERTED L" antenna be used. However, this type of antenna may not have sufficient capacity to match the impedance of the transmitter output network in the frequency range 2000 KC to 3000 KC. Therefore, the "ANTENNA" SHUNT CAPACITOR UNIT has been supplied to permit antenna matching when operating within the above frequency range, and is connected to the "COND" terminal on the transmitter.

CAUTION

When using the fixed wire antenna within the frequency range of 200 to 500 KC, extreme caution should be taken to keep the antenna lead-out well in the clear of other objects, as the voltages built up on the fixed antenna are extremely high. In general, the trailing wire antenna should be used for this frequency range, whenever possible.

For the low frequency band, it is more desirable to use the trailing wire antenna. Due to the fairly wide range of impedances obtainable from the antenna coupling network of the transmitter, only 200 ft of antenna are required to match the antenna to the power amplifier output.

Should the trailing wire antenna be used for the high frequency operations, it will be necessary to connect the antenna jumper from the trailing wire, to the "ANT" terminal on the transmitter. Increased radiation will be secured if the antenna is any odd number of quarter wave lengths of the frequency being used.

9. POWER OUTPUT RATINGS.—The power output ratings for the AN/ART-13 transmitter are as follows:

Below 25,000 ft	Frequency-KC	Power Output-Watts
Trailing Wire Antenna	200	5.5
	300	14.0
	400	18.0
	500	24.0
	600	28.0
Fixed Wire Antenna	2000	31.0
	3000	60.0
	4000	80.0
	5500	90.0
	7000	90.0
	9000	90.0
	11,500	90.0
	13,500	90.0
15,500	75.0	
18,000	65.0	

The actual power output of the equipment will vary greatly, depending upon the efficiency of the antennae used, and will generally be much greater than rated power output.

10. FREQUENCY CHANGE SYSTEM.—The positioning accuracy of the Autotune system is of a very high order requiring approximately 25 seconds for tuning to one of eleven preselected frequencies. Provisions have also been made to permit manual tuning of the radio equipment.

(2) OPERATION OF RAX-1 RECEIVERS.

(See figure 43.)

(a) GENERAL.—The RAX-1 receiving equipment is designed for reception of radio signals in the frequency range from 0.2 to 27 megacycles. This is accomplished by the use of three receivers as follows:

1. Receiver No. 1 covers a frequency range 0.2 to 1.5 megacycles with a four band switch arrangement.

2. Receiver No. 2 covers a frequency range 1.5 to 9.0 megacycles with a four band switch arrangement.

3. Receiver No. 3 covers a frequency range 7.0 to 27.0 megacycles with a five band switch arrangement.

Power for the dynamotor to each receiver is controlled by the radioman's master power switch.

(b) OPERATIONAL CHECK.

1. RADIOMAN.

a. Place "MCW-OFF-CW" switch to MCW or CW position, whichever emission is desirable. This switch also controls the power to the receiver.

b. Set the "BAND CHANGE" switch to the band which includes the desired frequency.

c. Insert the headphone cord plug into the "PHONE" jack of jack box.

d. Set the "AVC-MAN" switch to AVC (Automatic Volume Control) or MANUAL position depending upon what type of emission is received.

The receiver sensitivity for weak signals will be maximum when the volume control is at maximum position, regardless of whether the "AVC-MAN" switch is in the AVC or MANUAL position. Ordinarily, the AVC position should be used for radio-telephone signals to avoid fading of signals. MANUAL should be used for CW reception since, on AVC, the time constant of the AVC circuit would cause the receiver sensitivity to vary during the keying.

The automatic gain control tube holds the level of the audio output in the telephone receiver at a substantially constant level for all values of incoming radio signal strength above a certain minimum. Thus, when the "AVC-MAN" switch is in AVC position, this constant audio output may be varied by use

of the volume-control knob, but it cannot be increased above the level to which the AVC tube is set.

2. PILOT.—Any of the three receiver signal outputs can be fed into the flight crew jack boxes by the following operations:

a. Insert headphone cord plug into "PHONE" jack of jack box.

b. Place "RADIO OP'S. A-TEL RAX-1" or "RADIO OP'S. B-TEL RAX-1" or both to "ON" position, depending upon which receiver combination is desired.

Note

When the AN/ART-13 transmitter is keyed, the antenna lead-in to the receivers is grounded, and a side tone is fed into the jack box.



Figure 43—RAX-1 Receiver



(3) OPERATION OF AN/ARC-5 LIAISON RECEIVER.

(a) GENERAL.—The AN/ARC-5 radioman's receiver operates from 3-6 MC. However, any of the independent receiving units specified in COMMAND TRANSMITTING-RECEIVING EQUIPMENT can be installed and operated.

(b) PRELIMINARY ADJUSTMENTS.

1. Place "BATTERY" switch on main distribution panel to "ON" position.

2. Place "RADIO" switch on radioman's power box to the "ON" position.

3. Insert headphone cord plug into "PHONE" jack of jack box.

(c) OPERATIONAL CHECK.

1. RECEIVING.

a. Turn "CW-VOICE" switch on tuning control to CW for reception of continuous-wave keyed signals or to "VOICE" for reception of voice or tone-modulated signals.

b. Place "RADIO OPS. H.F. ARC-5" switch on interphone control box to the "ON" position.

c. Rotate "VOLUME" control on interphone control box to maximum position.

d. Tune to the desired frequency as indicated on the direct-reading tuning dial.

e. Adjust volume control on tuning control unit to maximum tolerable signal output or noise level.

Note

The method of providing a SIDETONE at the "MIC" is presented in the note following paragraph (2), (b), 2, b under OPERATION OF PAX-1 RECEIVERS.

(4) OPERATION OF LM-14 FREQUENCY METER

(See figure 44.)

(a) GENERAL.—The model LM-14 crystal calibrated frequency meter is specially designed to provide a simple, accurate and reliable frequency indicating equipment of the crystal calibrated type. It is adaptable for adjusting adjacent radio transmitters and receivers to any desired frequency in the range from 125 to 20000 KC. The equipment provides accuracies of 0.02 per cent in the 125 to 2000 KC. band and 0.01 per cent in the 2000 to 20000 KC. band at any ambient temperature in the range from minus 32 to plus 65 degrees centigrade.

(b) PRELIMINARY ADJUSTMENTS.

1. Radioman's AN/ARC-5 communication receiver must have power "ON."

2. Place "FIL" power switch in the "ON" position. Allow approximately 10 minutes for tube filaments to heat.

3. Place the "PLATE" power switch in the "ON" position.

4. Set the "FREQ. BAND" switch to "HIGH" or "LOW," whichever is desired.

5. Place the "MODULATION" switch to the "OFF" position.

6. Place the "CRYSTAL" switch to the "OFF" position.

(5) OPERATIONAL CHECK.

(a) RECEIVER—CW.—To tune a CW receiver to a desired frequency, proceed as follows:

1. Turn the frequency meter tuning control to the dial setting of the desired frequency as given in the calibration book.

2. Insert headphone cord plug into output of receiver being calibrated.

3. With the "RF CPLG" pick-up lead loosely coupled to the receiver antenna lead, tune the receiver to give an audible signal in the headphones.

4. Adjust the "RF COUPLING" to give the desired signal strength.

Note

Operational steps of (5), (a) should be accomplished in the shortest possible interval; otherwise, voltages and/or temperature changes may cause the frequency meter to drift.




Figure 44—LM-14 Frequency Meter




Figure 45—AN/ARC-5 Receiving Equipment

(b) RECEIVER.—MCW.—To tune an MCW receiver to desired frequency, proceed as follows:

1. Repeat preliminary adjustments in (4), (b) except "MODULATION" switch should be turned to the "ON" position.

2. Repeat all steps in (5), (a).

(c) TRANSMITTER ADJUSTMENT.—Briefly, the method of adjusting a transmitter to a desired frequency consists of zero beating the transmitter frequency with the proper heterodyne oscillator frequency, effecting the comparison by means of a pair of headphones plugged into the "PHONES" jack located on the front panel of the frequency meter. The "CRYSTAL" and "MODULATIONS" switches should be in the "OFF" position during the process.

Specifically the procedure is as follows:

1. Turn the frequency meter tuning control to the dial setting of the desired frequency, as given in the calibration book.

2. With the frequency meter pick-up lead closely coupled to the transmitter output, tune the transmitter to give an audible beat in the phones.

3. Adjust the "RF COUPLING" control to obtain a comfortable signal level in the headphones.

4. Tune the transmitter to zero beat with the frequency meter.

c. OPERATION—COMMAND
TRANSMITTING—RECEIVING
EQUIPMENT—AN/ARC-5.

(See figure 45.)

(1) GENERAL.

(a) The Model AN/ARC-5 aircraft equipment is a complete multi-channel radio transmitting and receiving set. The equipment is designed to transmit and receive voice, tone-modulated, or continuous-wave signals. The receivers cover the frequency range of .19 MC. to 9.1 MC. in five independent units any two of which may be installed and operated at a time or simultaneously. The bands are .19-.55 MC., .52-1.5 MC., 1.5-3 MC., 3-6 MC., 6-9.1 MC. The HF (high frequency) transmitters cover the frequency range of 2.1 MC. to 9.1 MC. in five independent units any one of which may be installed and operated, depending upon the requirements. The bands are 2.1-3 MC., 4-5.3 MC., 5.3-7 MC., 7-9.1 MC.

(b) The VHF (Very High Frequency) equipment is designed to transmit and receive voice or tone-modulated signals. The VHF transmitter contains four crystal-controlled channels, "A" of which is in 100-124 MC. band, "B" and "C" of which are in the 122-146 MC. band, and "D" of which is in the 132-156 MC. band. The VHF receiver ordinarily operates on the same four frequencies as the VHF transmitter, and is also crystallized control.

(2) PRELIMINARY ADJUSTMENTS.

(a) Place "BATTERY" switch on main distribution to "ON" position.

(b) Place "RADIO" switch on pilot's switch panel to "ON" position.

(c) Insert microphone cord plug and headphone cord plug into "MIC" and "PHONE" jack, respectively, of jack box.

(3) OPERATIONAL CHECK.

(a) RECEIVING—FREQUENCY RANGE
.19-1.5 MC.—NAVIGATION.

1. Turn "CW-VOICE" switch to CW for reception of continuous-wave keyed signals or to "VOICE" for reception of voice or tune-modulated signals.

2. Rotate selector switch on interphone control to "VOICE" or "BOTH" position.

3. Place "PILOT'S RANGE RECEIVER" in the "ON" position.

4. Rotate "VOLUME" control on interphone control box to maximum position.

5. Tune to the desired frequency on the tuning unit as indicated on the direct-reading tuning dial.

6. Adjust volume control on tuning control unit to maximum tolerable signal output or noise level.

Note

When using the navigation receivers for reception of radio range, homing or direction finder signals, keep the manual sensitivity control at a setting corresponding to the weakest usable signal. If the sensitivity is not reduced manually to a low value when receiving radio, homing, or direction finder signals, the course indication will be broad due to AVC (Automatic Volume Control) action.

(b) RECEIVING—FREQUENCY RANGE
1.5-9.1 MC. COMMUNICATION.

1. Turn "VOICE-CW" switch on tuning control unit to CW or VOICE whichever is desired.

2. Place "PILOT'S H.F. ARC-5" switch on the interphone control box to the "ON" position.

3. Rotate "VOLUME" control on interphone control box to maximum position.

4. Tune to the desired frequency as indicated on the direct-reading tuning dial.

5. Adjust volume control on tuning control unit to maximum tolerable signal output or noise level.

Note

When using the communication receivers, keep the manual sensitivity control at a setting corresponding to the maximum tolerable noise level. The built-in AVC will automatically adjust the sensitivity of the receiver to weak or strong signals over a wide range.

(c) TRANSMITTING—HF AND VHF.—Operation of the HF or VHF transmitters by the flight crew is as follows:

1. Place the emission selector switch or transmitter control box to "VOICE," "CW" or "TONE," whichever is desired.

2. Press channel button A, B, C, or D as required. This selects the frequency for both the VHF transmitter and VHF receiver. For operation on HF transmission press channel button No. 2. Allow thirty seconds for tubes to warm-up before proceeding.

3. Rotate the four position selector switch on the interphone control box to "VHF-HF TRANS." position.

4. Close the "PRESS TO TALK" button on the microphone.

Note

1. Channel button No. 3 is inoperative and if pressed accidentally, the sidetone will be heard in the headphones, but no signal will go on the air.

2. WAIT FOUR SECONDS AFTER PRESSING EITHER A, B, C, OR D CHANNEL SELECTOR BUTTON BEFORE PRESSING BUTTON NO. 2.

If this is not done, the switching motor will continue to run. It can be stopped by pressing one of the A, B, C, or D buttons.

(d) RECEIVING—VHF—FLIGHT CREW.—Operation of VHF receiver by flight crew is as follows:

1. Place emission selector switch on transmitter control box to "VOICE," "CW," or "TONE," whichever is required.

2. Press channel selector button A, B, C, or D for the desired frequency. This switches the transmitter and receiver to the same frequency.

3. Place the "PILOT'S VHF ARC-5" switch on the interphone control box to the "ON" position.

4. Adjust the "VOLUME" control on interphone control box to maximum tolerable signal output.

(e) RECEIVING—VHF—CREW.—Operation of VHF receiver by crew members is as follows:

1. Instruct pilot to place VHF receiver into operation as explained in (d) steps 1 and 2.

2. The VHF receiver audio output is always connected through the interphone amplifier to the crew interphone station box until interrupted by pressing the "PUSH TO TALK" button on the microphone.

(f) TRANSMITTING—HF, VHF—CREW.—Operation of HF or VHF transmitters by crew members is as follows:

1. Instruct pilot to place HF or VHF transmitter into operation as explained in paragraph (3), (c), 1, 2 and 3.

2. Instruct pilot to place "ICS-RADIO TURRET STATIONS" switch to "RADIO TURRET STATIONS" position.

3. Rotate three position selector switch on interphone crew station box to "RADIO" position.

4. Close the "PRESS TO TALK" button on the microphone.

d. OPERATION OF INTERPHONE SYSTEM. (See figures 10 and 46.)—The Interphone system provides two-way intercommunication between all crew members; by proper control of selector switches, it is possible to receive radio signals.

(1) PRELIMINARY ADJUSTMENTS.

(a) Power for both interphone dynamotors is obtained by turning "ON" the "BATTERY" switch located on the main distribution panel.

(b) The selector control switch on the RL-24C amplifier must be on "ICS ALL" position, No. 4.

(c) Turn the ICS "ON-OFF" switch on the amplifier to "ON" position.

(d) Turn the power "ON-OFF" switch on the amplifier to "ON" position.

(e) Turn "VOLUME" control to desired position.

(2) OPERATIONAL CHECK.

(a) CREW TO CREW.—The following is necessary at crew station boxes:

1. Insert the microphone and headphone cord plugs into "MIC" and "PHONES" jacks, respectively.

2. Rotate selector switch to "ICS CREW" position.

3. Close the "PRESS-TO-TALK" button on the microphone.

(b) CREW TO ALL CREW.—The following is necessary at crew station boxes and flight crew jack boxes:

1. Insert the microphone and headphone cord plugs into "MIC" and "PHONES" jacks, respectively.

2. Rotate selector switch on station box to "ICS ALL" position.

3. Close the "PRESS-TO-TALK" buttons on the microphone.

(c) FLIGHT CREW TO ALL CREW.—The following is necessary at flight crew control box and jack box:

1. Insert the microphone and headphone cord plugs into "MIC" and "PHONES" jacks, respectively, of jack box.

2. Rotate the four position selector switch to "ICS" position.

3. Close the "PRESS-TO-TALK" button on microphone.




Figure 46— RI-24C (Mod.) Interphone System

e. NAVIGATION RADIO EQUIPMENT.

(1) SCR-269-F RADIO COMPASS.

(See figure 47.)

(a) GENERAL.—The SCR-269-F Radio Compass is a complete unit capable of providing:

1. Automatic bearing indication of the direction of arrival of radio frequency energy and simultaneous aural reception of modulated or unmodulated radio frequency energy.

2. Aural reception of modulated or unmodulated radio frequency energy using a non-directional antenna.

3. Aural reception of modulated or unmodulated radio frequency energy using loop antenna.

4. Aural-null directional indications of the arrival of modulated or unmodulated radio frequency energy using a loop antenna.

(b) PRELIMINARY ADJUSTMENTS.

1. Turn "RADIO" switch on pilot's switch panel to "ON" position.

2. Insert telephone cord plug into "PHONE" jack of jack box.

3. Rotate selector switch on interphone control box to "RANGE" or "BOTH" position. Also, set "PILOT'S COMPASS RECEIVER" to "ON" position.

4. Set the radio control box switch to "COMP." or "ANT." position.

5. Push "CONTROL" switch to operate green light. The green light identifies the radio control box in control.

6. Rotate the band switch to the frequency band in which operation is desired.

7. Turn "TUNING" crank to the desired station frequency in kilocycles, and rotate back and forth through resonance to determine the exact setting of the dial for maximum clockwise reflection of the tuning meter. Listen for station identification to be sure the correct station is being received.

8. Radio Compass SCR-269-F provides for aural identification of keyed CW stations by means of internal modulation controlled by the "CW-VOICE" switch. Switch to "CW" when this type of operation is desired.

(c) OPERATIONAL CHECK.

1. HOMING COMPASS OPERATION.—

For homing operation perform the operations of foregoing paragraph (2), (b), and proceed as follows:

a. Switch to "COMP."

b. Apply rudder in the direction shown by the indicator pointer. When the indicator pointer is at zero, the aircraft is headed toward the radio station. The indicator pointer always points toward the radio station. If the pointer is to the right of zero, the station is to the right of the aircraft's heading.

c. Adjust "AUDIO" or Interphone control for satisfactory headset level.

d. Since in "COMP." operation, the equipment has an excellent automatic volume control action, it is not practical to home on a radio range course and fly it aurally at the same time.

e. Radio compass homing operation is such that aircraft will ultimately arrive over the radio station antenna regardless of probable drift due to cross wind. However, the flight path will be a curved line, and coordination with ground fixes or landing fields along the route will be either difficult or impossible. Consequently, it is often expedient to fly a straight-line course by off-setting the aircraft's heading to compensate for wind drift. To do this, determine the wind drift, either with the drift sight or by noting the change in magnetic compass reading over a period of time while homing with the radio compass. A decreasing magnetic bearing indicates a wind from the left while an increasing magnetic bearing indicates a wind from the right. By trial and error, find the correct upwind radio compass angle, as shown by the indicator pointer providing the minimum rate of change of magnetic compass reading. The scale on the indicator shows the deviation of the aircraft's heading from the direction of the radio station, directly, in degrees.

2. DIRECTION FINDING — VISUAL METHOD.—For operation as an automatic visual indicating direction finder, perform the operations as listed under PRELIMINARY ADJUSTMENTS, paragraph (1), (b) and proceed as follows:

a. Switch to "COMP."

b. Prior to making fix determinations, the stations to be used should be located on the map, tuned in, identified, and the dial reading logged. This avoids delay and error at the time of obtaining the fix.

c. For best accuracy, several bearings should be taken in rapid succession thereby eliminating error caused by the distance traveled between bearing observations. Bearings cannot be accurate unless the aircraft is held on a steady heading.

d. Adjust "AUDIO" or Interphone control at Interphone control box for desired headset level.

e. Determine the magnetic variation for the locality over which the aircraft is passing.

f. Record the bearing shown by the tail end of the bearing indicator pointer. (This will be station-to-aircraft bearing from north.)

g. To obtain a fix, take bearings on three or more stations 30 degrees or more from the line of direction of any one station, and plot them on a map. The intersection of the plotted lines is the position of the aircraft at the time of observation.

3. DIRECTION FINDING—AURAL-NULL METHOD.

a. Switch to "LOOP," push "CONTROL"

switch to obtain green light, and tune in desired station as in paragraph (1), (b). When listening for station identification, it may be necessary to rotate the loop to a maximum signal position to obtain a good intelligible signal. The aural width of the loop null may be decreased somewhat by using "CW" operation. "CW" operation is also necessary to identify keyed "CW" stations.

b. Adjust "AUDIO" or Interphone control at Interphone control box for desired headset level.

c. Determine the magnetic variation for the locality.

d. Using "LOOP L-R" switch, rotate the loop for minimum headset volume and read the bearing indicator. If the signal null exists over too wide an angle, greater accuracy may be obtained by placing the "AUDIO" knob fully clockwise and locating the null by either listening for the disappearance of the audio signal or noting the dip in tuning meter deflection.

e. Record the bearing shown by the tail end of the bearing indicator pointer. Bearings are subject to 180 degree ambiguity.

4. RECEIVER RECEPTION—ANTENNA OPERATION.—Perform the operation described in paragraph (1), (b) and proceed as follows:

a. Set function switch to "ANT." and adjust the interphone "VOLUME" control or the "AUDIO" knob of the radio control box for satisfactory headset volume.

b. For the best definition of radio range signals (between 200 and 420 kc), set the Interphone control fully clockwise and adjust the "AUDIO" knob for the lowest usable headset volume.

5. RECEIVER RECEPTION—LOOP OPERATION.

a. If reception on antenna is noisy because of precipitation static, commonly known as rain or snow static, possibly loop reception may be employed for better results. Turn function switch to "LOOP" position. Depress "LOOP L-R" knob and turn to "L" or "R," holding until maximum signal strength is obtained. Adjust the "AUDIO" knob for desired headset volume. To rotate loop at slow speed do not depress "LOOP L-R" knob when turning it to "L" or "R."

b. For the best definition of radio range




Figure 47—SCR-269-F Radio Compass

signals on "LOOP," it is necessary to maintain the loop near the 90 or 270 degree position, set the interphone control fully clockwise, and adjust the "AUDIO" knob for the lowest usable headset volume.

(d) PRECAUTIONS DURING OPERATION.

1. AURAL RECEPTION OF A-N SIGNALS.—For aural reception of A-N signals, operate the equipment on "ANT." or "LOOP" instead of "COMP.," since the action of the AVC in the "COMP." position will cause broad course indications.

2. BEST DEFINITIONS OF A-N SIGNALS.—For best definitions of A-N signals on "ANT." or "LOOP," the "AUDIO" control must be set to the lowest usable audio level and must be reduced as A-N signals increase.

3. PRECIPITATION STATIC.—During periods of precipitation static, operate on "LOOP"; for best reception, rotate the loop until a maximum signal is obtained.

4. AURAL RECEPTION ON INTERPHONE.—For aural reception of A-N signals on Interphone, the Interphone "VOLUME" control must be set fully clockwise and the "AUDIO" control on the compass control box used to reduce headset volume. This is essential to obtain proper course definition.

5. DIRECTION BY AURAL-NUL METHOD.—When determining direction on "LOOP" by aural-null method, there is an 180 degree ambiguity and the direction of the station may be 180 degrees from the null obtained. The broadness of the null with aural-null direction finding depends on the strength of the signal. Strong fields produce very sharp nulls, sometimes as small as one tenth degree. Vary "AUDIO" control until null is of satisfactory width. The tuning meter may be used as a visual null indicator.

6. LOOP OPERATION.

a. If the loop should be in the null position when flying on a radio range course, the signal may fade in and out and possibly be mistaken for a cone of silence.

b. Cone of silence indications are not reliable on loop type radio range stations, when the radio compass is operating on "LOOP". The signal may increase in volume to a strong surge when directly over the station instead of indicating a silent zone.

7. SELECT RADIO STATIONS PROVIDING STABLE BEARING.—Tune equipment carefully. If an interfering signal is heard in the headset, it is probably causing an error in bearing. To check, tune a few kilocycles either side of resonance. A change in bearing with tuning indicates an interfering signal. If station interference exists, select another station or proceed by other means of navigation until closer to the desired station. Care must be exercised when taking bearings on stations broadcasting the same program, as

they may be mistaken for another station. Avoid taking bearings on synchronized stations, except close to the desired station. If the radio station stops transmitting, or fades, especially code stations operating in a network, bearings might be taken on other stations of the same frequency, thus causing errors. Do not use a station for bearings unless it can be identified by the headset signal on "COMP." operation.

8. NIGHT EFFECT.—Night effect, or reflection of the radio wave from the sky, is always present. It may be recognized by a fluctuation in bearings. The remedy is: either (a) increase altitude, thereby increasing the strength of the direct wave; (b) take an average of the fluctuations; or (c) select a lower frequency station. Night effect is worse at sunrise and sunset. Night effect may be present on stations at 1750 kc at distances greater than 20 miles. As the frequency decreases, the distance increases, until, at 200 kc the distance will be about 200 miles. Satisfactory bearings, however, will often be obtained at much greater distances than stated above, and sometimes, unsatisfactory bearings may be obtained at shorter distances.

9. TO OBTAIN ACCURATE STATION BEARINGS.—When close to a station accurate bearings cannot be taken with the aircraft in a steep bank.

Only head-on bearings are entirely dependable. If side bearings are taken, keep the wings horizontal.

Do not depend on two stations for a fix of location; at least three station bearings should be used. In general, a set of stations with bearings spaces approximately at equal intervals throughout 360 degrees will give best accuracy.

10. OPERATION UNDER ADVERSE WEATHER CONDITIONS.—This equipment should provide compass bearings during conditions of moderate precipitation static which interrupt normal reception. On occasions where severe precipitation static is present, especially when discharges occur from parts of the aircraft surfaces, it will be necessary to operate on "LOOP" position. In this position, satisfactory reception and aural-null direction finding will be possible most of the time. The type of precipitation static existing in air mass fronts at different temperatures can be avoided by crossing the air mass front at right angles and then proceeding on desired course instead of flying along the air mass front.

11. "CW-VOICE" AND "COMP." OPERATIONS.—When receiving modulated signals, intelligibility is greatly reduced as the "CW-VOICE" switch is set to "CW". Operation of the equipment when the function switch is set to "COMP." is not affected by the position of the "CW-VOICE" switch.

12. "MOUNTAIN EFFECT".—Erroneous or fluctuating bearings, in some instances, are produced by reflection of radio waves from the mountains. This phenomenon is called "MOUNTAIN EFFECT". Be-

cause of this effect, bearings taken when flying over mountainous terrain should not be relied upon explicitly.

(2) AN/APN-1 RADIO ALTIMETER.

(See figures 4 and 48.)

(a) GENERAL.—The model AN/APN-1 Radio Altimeter equipment is designed to provide direct indication of altitude relative to the terrain during flight. The equipment is provided with a double range indicator to allow altimeter readings from zero to 400 ft or 400 to 4000 ft.

CAUTION

1. Operating personnel are not to disturb any of the screwdriver adjustments on the front panel of the Radio Transmitter-Receiver. These adjustments are accessible externally only for the convenience of qualified installation or maintenance personnel when calibrating the equipment.
2. The high range of the altimeter must not be used when flying at altitudes within the low range, or when landing. The high range is not calibrated for such use and an accurate zero altitude indication will not be obtained.
3. When the aircraft is resting on the ground, the Altitude Indicator pointer may not indicate zero altitude. Never attempt to adjust the equipment to obtain a zero reading for this condition.

(b) OPERATIONAL CHECK.

1. Place "RADIO" switch on the pilot's switch panel to the "ON" position.
2. Rotate power switch knob on the Indicator in the "ON" direction. After allowing approximately one minute for the tubes to heat, observe that the pointer of the Altitude Indicator has moved from its sub-zero stop position, indicating that the equipment is energized.
3. Place the "RANGE" switch on the Altitude Indicator to the high range or low range, depending upon the altitude of the airplane. (See second paragraph of CAUTION note following (2) (a) above.)
4. Rotate the Altitude Limit Switch to the desired altitude setting. This setting determines the altitude at which the Radio Transmitter-Receiver will actuate the Altitude Limit Indicator lights.

5. Altitude Indicator will give true indications of altitude, over the entire range of the equipment, when flying over rough or uneven terrain, or when flying through bumpy air.

(c) ALTITUDE LIMIT INDICATOR.—This auxiliary device relieves the pilot of the constant attention to the Altitude Indicator scale. It consists of three colored lamps, one of which is illuminated for each of the three conditions of relay contact operation.



Figure 48—Radio Altimeter Transceiver

1. RED.—Indicates flight below the preset altitude control range determined by the Altitude Limit Switch setting.
2. WHITE.—Indicates flight within the preset altitude control range.
3. GREEN.—Indicates flight above the preset altitude control range.

(d) FUSES.—The AN/APN-1 Altimeter equipment is protected against damage from short-circuits by a fuse of three-ampere rating located at the lower right-hand corner of the front panel of the Radio Transmitter-Receiver. A spare fuse of corresponding rating is provided in an adjacent receptacle.

CAUTION

If necessary to make any substitution for the fuses (type 4AG Littlufuse) which are supplied with the equipment and spare parts, use "slow-blowing" fuses of the same current capacity if available. If not available, substitute fuses of the next higher current rating for TEMPORARY EMERGENCY USE ONLY.

(3) AN/ARN MARKER BEACON RECEIVER.
(See figure 49.)

(a) GENERAL.—The AN/ARN-8 receiver is a fixed tuned receiver providing two audio outputs and one visual output. It operates on a frequency of 75 megacycles. The first audio output is heard by the copilot and radioman, and the second is heard by the pilot. The two received signals differ only in their modulation frequency. In addition, the received signal actuates an indicator light on the pilot's instrument panel. The pilot thus receives both an aural and visual indication when the airplane passes over the marker beacon transmitting station.




Figure 49—AN/ARN-8 Marker Beacon

(b) OPERATIONAL CHECK.

1. Check the toggle switch on the upper left corner of the receiver panel. This switch must be in the "ON" position at all times.

2. Insert headphone cord plug into "MIC" jack of jack box.

3. Place "MARKER BEACON" switch in the "ON" position. When the airplane passes over a marker beacon, the indicator will turn on and an aural signal will be heard.

4. AN/APN-4 EQUIPMENT.—Operating instructions for this equipment may be found in CONFIDENTIAL operating instruction manual CO-AN 08-25CA-1.

f. RADAR EQUIPMENT.—Operation of the following Navy aircraft radar equipment can be found in CONFIDENTIAL operating instructions manuals:

AN/APX-2	AN 08-10-192
AN/APS-3	AN 08-10-196

4. ARMAMENT.

The airplane is equipped with three .30 caliber and two .50 caliber machine guns. Two .30 caliber machine guns are located in the bow enclosure, one .50 caliber in each of the side waist blisters, and one .30 caliber in the tunnel gun position.

In addition, provisions are made to mount two blisters equipped with ball and socket mounts for a .30 caliber gun in the tunnel gun compartment.

On the wing there are four Mark 51-7 internal bomb racks and provisions to mount four Mark 51-7 ex-

ternal bomb racks mounted in a torpedo rack. There are also provisions for four Mark 42 bomb racks.

a. BOW GUN.—Two .30 caliber machine guns are mounted in the bow enclosure. The guns are installed on a plexiglas shell in a revolving circular windshield. To the right of the gunner, provisions are made to stow four ammunition containers of 350 rounds capacity. Two more ammunition containers are installed on the mount, making a total of 2100 rounds of ammunition.

To stow guns:

Rotate the windshield until the guns are pointed directly forward.

Lock the enclosure with the function lock located to the left of the gun mount.

Deflect the guns until they hit the stop.

Pass the strap that is fastened to the enclosure bulkhead underneath the adapter and pull up tight.

The bow guns are readied for firing by unfastening the stowage strap. (See figure 50.)

During take-off and landings the bow enclosure is kept watertight by inflating sealing tubes by a hand pump located to the left of the gunner. Instructions for operating the hand pump are located near the hand pump. A valve for releasing the air in the sealing tubes is integral with the latch.

b. SIDE WAIST GUNS. (See figure 51).—One .50 caliber machine gun is located in each of the side waist blisters between bulkheads 6 and 7. Provisions are made for 956 rounds of ammunition for the two side waist guns.

A firing guard is provided for each side gun to prevent the gun from being fired into the tail, or the aft portion of the hull. The firing guard is a three-quarter inch steel tube attached to the hull just below the blister. When the rotating shield of the gun blister is raised for firing the gun, the firing guard is lifted and attached to the clamp on the rotating shield. Before the gun blister is closed, the firing guard must be placed in its stowed position. (See figure 52.)




Figure 50—Bow Guns in Firing Position



Figure 51—Side Waist Guns Firing



Figure 52—Side Waist Guns Stowed

The gun is stowed on the mount in a fore and aft position. The muzzle rests in a cradle and is secured with a metal strap. To stow the gun:

Swing the gun inside the airplane with the muzzle pointing aft.

Close and lock rotating shield of gun blister.

Secure the muzzle with the metal strap.

When closed, the transparent gun blisters are kept watertight by the same method used for the bow gun enclosure.

Switches controlling the Mark 9 gun sight, continuous feed ammunition boosters (See figure 55) and gun camera are on either side of the hull, forward of the gun posts. Before either the gun sight or gun camera will operate, the switch on the main distribution panel must be on.

c. TUNNEL GUN. (See figures 53 and 54.)—To place the gun in firing position:

Unlatch the spade grip.

Swing the gun and stirrup up and out of the stowed position.

Unfasten the toggle lock holding stirrup to Vee brace.

Lower stirrup from vertical position.

Screw the locking nut tight.

To place the gun in stowed position:

Unscrew the locking nut.

Swing the stirrup into vertical position.

Fasten the stirrup to Vee brace with the toggle lock.

Swing the gun and stirrup above the Vee brace hinge into stowed position at port side of hull.

Place barrel in stowage hook and latch spade grip in place.

Unfasten tunnel door, swing it down into horizontal position, and latch the door.

A gun camera receptacle and switches are on the port side of the hull, adjacent to the latch. The switch on the main distribution panel must be on before power will feed through the receptacle.

Provision for 500 rounds of ammunition is provided.

d. CAMERAS.—Provision is made at the two waist guns and the tunnel gun for the installation of a G.S.A.P. camera. To allow for adjustment when bore-sighting, the camera mount has oversize holes which permit sufficient movement of the camera to bring the line of sight of the camera parallel with the axis of the gun. After the camera is properly aligned, it is secured by tightening and safeying the bolts.

Provision is made for the installation of a torpedo training camera immediately forward of station 1.66 on top of the pilot's enclosure.

e. BOMB EQUIPMENT.

(1) BOMB LOADS.—The bomb load consists of any one of the following:

Two demolition bombs (1000 pound class).

Four demolition bombs (500 pound class).

Four demolition bombs (1000 pound class).

Eight depth charges AN Mark 17-2 (325 pounds).

Twelve demolition bombs (100 pound class).

Two torpedoes Mark 13 or Mark 13-1 (1935 pounds with stabilizers).

Any of the following 1000 pound class bombs and fuses can be carried in the racks:

Mark 5 with Mark 21 nose fuse and Mark 23 tail fuse.




Figure 53—Tunnel Gun Stowed





Figure 54—Tunnel Gun—Ready



- | | |
|---------------------------|------------------------|
| 1. Ammunition Feed Chutes | 3. Assist Motors |
| 2. Firing Guards | 4. Ammunition Magazine |

Figure 55—Side Gun Feed Mechanism

Mark 9 with Mark 21 nose fuse and Mark 23 tail fuse.

Mark 13 with Mark 21 nose fuse and Mark 23 tail fuse.

Mark 7 water-filled practice bomb.

Any of the following 500 pound class bombs and fuses can be carried in the racks:

Mark 3-1 with Mark 21 nose fuse and Mark 23 tail fuse.

Mark 9 with Mark 21 nose fuse and Mark 23 tail fuse.

Mark 12 with Mark 21 nose fuse and Mark 23 tail fuse.

Mark 5 water-filled practice bombs.

Mark 11 water-filled practice bombs.

Any of the following 100 pound class bombs and fuses can be carried in the racks:

Mark 1-3 with Mark 19-1 nose fuse (this type can be carried on the Mark 42 racks only).

Mark 4 with Mark 19-1 nose fuse.

Mark 7 water-filled practice bombs.

Mark 15 water-filled practice bombs.

(2) BOMB AND TORPEDO RACKS.—The service bomb rack installation consists of four Mark 51-7 bomb racks. The racks are mounted inside the center section of the wing near the lower skin surface. They are placed two on each side of the airplane, outboard of the nacelles. Access to the racks is through openings in the bottom of the wing. These racks remain installed in the airplane at all times, even though external racks are installed for carrying torpedoes, depth bombs, or 100 pound bombs. On the bomber's switch panel these four racks are referred to as "MARK 51 INTERNAL."

External bomb racks are installed to carry torpedoes or depth bombs. These racks are mounted outside and below the center section of the wing, one on each side of the airplane, outboard of the wing struts, and inboard of the internal bomb racks. These racks are not normally carried but installed only for a particular mission. (See figure 56.)

Each external bomb rack assembly consists essentially of members for attaching two Mark 51-7 bomb racks to the wing, together with the necessary electrical and manual control connections and splash fairings.

For the torpedo installation chocks, a starting lanyard attaching angle, and stop bolt installations are required. Each assembly carries one 1935 pound torpedo, Mark 13 or Mark 13-1, with air stabilizer.

In addition to the Mark 51-7 racks, provision is made for the installation of four Mark 42 practice racks. These racks are installed only for particular missions, and are not normally installed on the airplane. They are suspended externally beneath the wing, two in tandem on each side of the center line. Three 100 pound bombs per rack, or twelve in all, are carried on the Mark 42 racks.

The installation positions of the external racks, both Mark 42 and Mark 51-7 are marked on the underside of the wing.

(3) BOMBER'S COMPARTMENT.—The bomber's compartment is located in the nose of the airplane.

Provision is made for the installation of a Mark 15-5 bomb sight in the bomber's compartment.

The sighting window is provided with a metal cover that can be removed with the bomb sight in place. Stowage for the cover is provided on the forward port side of bulkhead 2.

A handhole, with a cover removable on the inside, is located immediately to the right of the sighting window. The handhole permits the bomber to clean the outside of the window during flight.

A bomber's instrument panel is located on the starboard side of the sighting window. Mounted on it are a free air thermometer, a lateral inclinometer, an air speed indicator and an altimeter. (See figure 57.)

(4) CONTROLS.

(a) GENERAL.—The controls are designed to permit either the bomber or the pilot to release bombs, either electrically or manually. The bomber sets up the electrical circuits and controls the selection of bombs to be released electrically, and the arming of the bomb fuses. The pilot (or copilot) has control of the release of the torpedoes. He can release them singly or together, electrically, or both together manually. Bombs and torpedoes are normally released electrically. Bomb fuses are armed electrically. The emergency salvo release controls are installed both in the bomber's and in the pilot's compartments. Those in the bomber's compartment serve for the salvo release of bombs. Those in the pilot's compartment serve for the salvo release of either bombs or torpedoes. The emergency salvo release will release bombs with fuses either armed or safe.

The bomber's electrical central switch panel is located in the port, forward corner of the bomber's compartment. (See figure 58.)

The bomber's firing key (NAF 1174) is stowed in a canvas bag in the port forward corner of the bomber's compartment.

The intervalometer, Mark 2-1, together with the intervalometer electrical panel, is mounted on the port side of the bomber's compartment. (See figure 59.)

The bomber's manual release handles are located on each side of the sighting window. The set on the port side controls the bomb racks on the port side of the airplane. The set on the starboard side controls




Figure 56—Torpedo Rack on Port Wing




Figure 57—Bombardier's Instrument Panel

the bomb racks on the starboard side of the airplane.

The pilot's switch panel has three switches and a firing key receptacle for use in releasing bombs or torpedoes.

The pilot's emergency release handles are mounted just below the pilot's instrument panel, one on each side of the center line.

(b) ARMING AND RELEASE SYSTEM.

1. ELECTRICAL CONTROL.—Switches on the bomber's switch panel provide for arming the fuses on either the Mark 42 bomb racks or on the Mark 51-7 bomb racks.

The bomber has the choice of two methods of electrical release, automatic and manual electric. In the automatic release the bomb sight will initiate the electrical impulse, which starts the functioning of the release system. The manual electric release requires that the bomber operate his firing key to provide the electrical impulse.

The automatic and the manual electric release each will release bombs selectively (one bomb or a salvo of several bombs released by an electrical impulse) or in a train (a series of bombs released by one electrical impulse, which activates the intervalometer).

Switches on the bomber's switch panel permit the bomber to set up the circuit, so that one or more bombs will be released by any of the methods described above.



The intervalometer Mark 2-1 is a multiwire intervalometer. Its electrical mechanism provides for the release of bombs in train. The bombs are released

successively so that their points of impact will be separated by that number of feet set by the bomber on the intervalometer.

The intervalometer assembly, in addition, includes electrical switches and jacks mounted on a panel and electrical wiring contained in the intervalometer box.

Four toggle switches are mounted on the upper left-hand corner of the intervalometer panel. From the left to right these control the circuits from the intervalometer to:

- Port outboard internal Mark 51-7 bomb rack.
- Port inboard internal Mark 51-7 bomb rack.
- Starboard inboard internal Mark 51-7 bomb rack.
- Starboard outboard internal Mark 51-7 bomb rack.






Figure 59—Intervalometer Panel

Electric circuits from the intervalometer proper to these racks are permanently installed, and to release one or more bombs from these racks by the intervalometer, it is only necessary to move the proper switches to the "ON" position.

Three sets of colored jacks are mounted on the intervalometer panel.

Eight yellow jacks are for the eight Mark 51-7 bomb racks. The panel is marked, indicating jack and its rack.

Twelve green jacks are for the 12 bomb positions on the Mark 42 bomb racks. The panel is marked, indicating jacks and their respective racks.

Fifteen red jacks are for the intervalometer impulses. These are not numbered, but operate in order as indicated below:

1	3	5	7	9	11	13	14
2	4	6	8	10	12	15	

By the use of plugs and jumper wires, any intervalometer impulse jack can be connected to any bomb rack jack, thus allowing the release of bombs by the intervalometer from any racks and in any order. If jumpers are connected to intervalometer impulse jacks Nos. 1, 2, 3 and 4, the toggle switches for Mark 51-7 internal racks should be set to the "OFF" position.

In the upper right-hand corner of the intervalometer panel there is a stand-by switch. This switch is "ON" for normal operation of the intervalometer. In case of intervalometer failure, the switch is turned to the "OFF" position. This breaks the electrical circuit through the intervalometer, and reconnects the circuit from the firing key through the rack selector switches to the bomb racks.

On the right-hand side of the face of the intervalometer, there is a master switch marked "OFF" and "ON." This switch must be "ON" for operation of the intervalometer. A red indicator light is below and to the right of the switch. The indicator light shows

when the electrical circuits are routed through the intervalometer and are energized.

On the lower left-hand side of the face of the intervalometer there are two concentric dials; the outer graduated in "Bomb Spacing Feet" from 20 to 200, and the inner graduation in "Ground Speed Knots" from 100 to 200. A knob for turning the inner dial is centered on the dial. By means of these dials, the intervalometer is set to send out electrical impulses so spaced that the impacts of the bombs released will be the desired distance apart.

After the proper switches are operated and the ground speed dial is set, the intervalometer operation will be activated either by a pressure of the firing key or by the bomb-sight.

The pilot's switch panel has three switches which affect bomb and torpedo release. Two of these switches are for torpedo selection. Operating these will connect the circuit to either or both torpedo racks, so that the pilot can release the torpedoes. This operation of releasing torpedoes is under the pilot's control and is independent of the bomber. There is a double-throw switch (with a red guard) marked "BOMB-TORPEDO." In the "BOMB" position, this switch sets up a circuit so that bombs can be released by the pilot, and cuts the bomber's firing key receptacle out of the circuit. In the "TORPEDO" position, the switch sets up a circuit so that torpedoes can be released by the pilot.

The pilot's switch panel has a receptacle for the pilot's firing key (NAF 1174). With the switches in proper position as explained above, operating the pilot's firing key will release either or both torpedoes.

With the "BOMB-TORPEDO" switch set to the "BOMB" position, the pilot can release bombs electrically, but only from the racks selected, and in the condition of fuse arming or safety, as set up by the bomber on his switch panel.

INTERVALOMETER TROUBLES

TROUBLE	CAUSE	REMEDY
Intervalometer fails to operate.	Electrical trouble in intervalometer.	Temporary remedy: Turn intervalometer main switch to "OFF" position. Operate bombing system without intervalometer. Permanent remedy: Remove and replace intervalometer. Have faulty intervalometer repaired.

2. **MANUAL CONTROL.**—The bomber's manual controls consist of two units; one to the left for the bomb racks on the port side of the airplane, and one to the right for the bomb racks on the starboard side of the airplane. Each unit has two handles connected by flexible cables to the bomb racks. The emergency release handle is marked "EMERGENCY RELEASE MARK 42 MARK 51." Pulling this handle will release all bombs on its side of the airplane in salvo. The Mark 42 safe and arming handle has two positions, marked "SAFE" and "MARK 42 ARMED." Pulling this handle to the armed position will arm the fuses of bombs carried on the Mark 42 racks. This handle is independent of the electrical fusing system.

The pilot's emergency release controls have two handles, mounted just below the pilot's instrument panel. One on the port side and one on the starboard side of the center line. The port handle controls bombs or torpedo on port side of the airplane and the starboard handle controls bombs or torpedo on starboard side of the airplane. The handle is connected by flexible cable and a cable splice plate to the bomber's emergency release cable.

A two inch pull on the cable is required to release the bombs. In adjusting the cables, turn the turnbuckles just enough to remove the slack in the cables and no more. Check to see that the emergency release handle is in the closed position, after the cables have been adjusted. Too great a tension on the cables may result in dropping bombs inadvertently.

3. BOMBING SYSTEM TROUBLES.

TROUBLE	CAUSE	REMEDY
Bomb rack fails to release.	If bomb cannot be released manually at rack, it is a bent, broken or rusted bomb rack. If bomb can be released manually at rack, it is a broken or stuck salvo release cable. Electrical circuit interrupted.	Remove rack and replace. Check cable. Replace broken section. Replace broken or warped pulley or bracket causing sticking. Check switches and fuses. If this does not correct trouble, then check circuit for continuity. Correct any faults discovered.

5. OPERATION OF CENTRAL HEATER.

(See figure 60.)

The central heater, located under the navigator's table, supplies heater air for cabin heating, windshield defrosting and engine preheating. The heater burns a mixture of gasoline vapor and air, the gasoline being obtained from the main fuel tanks of the airplane.

a. **CONTROLS.**—Controls for the heater consist of the following:

A switch located on the main distribution panel, marked "ANTI-ICERS AND HEATERS."

A switch located on the junction box at the aft end of the heater, marked "BAT.-GEN."

A combustion control located above and near the forward end of the navigator's table to start and stop the heater.

An air scoop which selects air either from the slip stream during flight or from the cabin during ground operation. This air scoop is located aft and above the navigator's table.

An exciter button located on the bottom of the junction box at the forward end of the heater, to increase fuel flow into the heater.

There are three outlets with dampers for distribution of heated air. The navigator's outlet is under the navigator's table near the forward end. The pilot's out-

let is at the pilot's left on bulkhead 2. The flight engineer's outlet is at the outboard end of the navigator's book case.

b. **TO START HEATER.**—Use the following procedure to start heater:

- (1) Close outside scoop.
- (2) Open fuel line shut-off valve.
- (3) Place main battery switch on. Place anti-icer and heater switch on. Place "BAT.-GEN." switch either on "BAT." or "GEN." in accordance with power source.
- (4) On combustion control, move control knob to "START" position. After a few minutes, when glow unit of heater is hot enough to ignite fuel, turn control switch to "RUN."
- (5) Through heater observation glass observe that fire starts.
- (6) If ignition is slow, momentarily press exciter button.

WARNING

Do not hold exciter button in.

- (7) When air-borne, open outside scoop.

c. **TO STOP HEATER.**—Press control stop button on combustion control. The fire will burn out in 10 to 15 minutes.

CAUTION

Close air scoop before water landing.

6. OPERATION OF PROPELLER WING AND TAIL ANTI-ICING SYSTEM.

a. **PROPELLER.**—The anti-icer control for propeller anti-icing fluid is a rheostat, located on the pilot's switch panel. Operation of the propeller anti-icer is accomplished as follows:

(1) Turn on fluid supply valve. This valve is located below reservoir on the aft face of bulkhead 4, port side.

(2) Turn "MAIN BATTERY" switch on at main distribution panel.

(3) Turn "ANTI-ICERS AND HEATERS" switch on at main distribution panel.

(4) Turn "ANTI-ICER" control to desired rate of flow.

b. **WING.** (See figure 9.)—The wing anti-icing system is designed to prevent formation of ice on the surfaces, rather than to de-ice the surfaces after ice has started to form. It is therefore important to start operating the system BEFORE ICING CONDITIONS ARE ENCOUNTERED. Anti-icer temperature gages are to the left of the flight engineer's seat. Automatic thermostatic controls dump hot air from ducts when temperature rises to 150°C (302°F).

Operation of the wing anti-icer is accomplished as follows:

(1) Turn "MAIN BATTERY" switch on at main power distribution panel.

(2) Turn "ANTI-ICERS AND HEATER" switch on at main distribution panel.

(3) Place "WING ANTI-ICER" switch in "OPEN" position on pilot's switch panel. If temperature rises above 150°C (302°F) the automatic control has failed. The switch should then be operated manually "ON" and "OFF" to keep temperatures below 150°C (302°F).

(4) Place "WING ANTI-ICER" switch in "CLOSED" position to shut off hot air supply.

c. **TAIL.**—The tail anti-icing system like the wing anti-icing system, should be turned on BEFORE ICING CONDITIONS ARE ENCOUNTERED.

Controls for the tail anti-icer consist of a fuel shut-off valve, located at the right of the flight engineer, and a switch and damper control, located on the forward face of bulkhead 7.

Operation of the tail anti-icer is accomplished as follows:

(1) Turn "MAIN BATTERY" switch on at main distribution panel.

(2) Turn "ANTI-ICERS AND HEATER" switch on at main distribution panel.

(3) Open fuel valve in flight engineer's compartment.

(4) Turn anti-icer switch on at bulkhead 7.

(5) Pull damper control lock down and pull damper control fully out, 30 seconds after turning on switch at bulkhead 7.

To shut off heater:

(1) Close fuel valve in flight engineer's compartment.

(2) Turn off anti-icer switch at bulkhead 7.

(3) Move air scoop control to "CLOSED" position.

(4) Turn off switch at main distribution panel.

CAUTION

Damper must be closed during take-offs and landings. It must be opened to second notch during operation of heater.

7. OPERATION OF AUXILIARY POWER UNIT.

(See figure 61.)

When preparing to start A.P.U., turn on fuel valve, which is located on the engineer's instrument panel. Make certain that A.P.U. generator switch, which is on the main distribution panel over the radio operator's table, is in the "OFF" position. Set the ignition switches in the "OFF" position. Engage the manual starter by depressing the starter rod handle and rotating the drum in a counter-clockwise direction. Then slowly turn the crankshaft through at least five revolutions by hand. Should it require undue effort to rotate the shaft, remove a spark plug from each cylinder to determine whether oil or gasoline has collected in the cylinders. Should any accumulation of oil or gasoline be found in the cylinders, the cause must be determined and remedied at once.

After the starting preparations have been completed, the engine should be started as follows:

Wrap the starting rope around the starter drum in a counter-clockwise direction.

Depress the manual starter rod handle; turn the drum slightly while the handle is being depressed; and, then, maintain a light tension to keep the starter gear engaged.

Turn the ignition switches to "ON" position.

Pull the rope through to spin the crankshaft. If the engine does not start at the first pull, repeat the process.

As soon as the engine starts, check the oil pressure gage to see that oil is being circulated under pressure.

CAUTION

If the gage does not register normal pressure within 30 seconds after starting, the engine must be stopped immediately and the cause of the trouble determined.

The engine will not attain its rated rpm immediately after starting because a thermostat in the crankcase is connected through a system of linkage to make the governor ineffective until the engine is thoroughly warmed up.




Figure 60—Central Heater




Figure 61—Auxiliary Power Unit

APPENDIX I

FLIGHT OPERATING CHARTS, TABLES CURVES AND DIAGRAMMS

1. Take-Off, Climb and Landing Chart. (See figure 62.)
2. Flight Operating Instruction Chart. (See figure 63.)
3. Cruising Chart. (See figure 64.)
4. Cruising Control Chart. (See figure 65.)
5. Engine Operating Limits Curve. (See figure 66.)

Appendix I

RESTRICTED
AN 01-5MC-1

AIRCRAFT MODEL(S)
P-1-B30-32

ENGINE MODEL(S)
P-1-B30-32

TAKE-OFF, CLIMB & LANDING CHART

TAKE-OFF DISTANCE FEET

GROSS WEIGHT L.B.	HARD SURFACE RUNWAY			SOFT-TURF RUNWAY			SOFT SURFACE RUNWAY						
	AT SEA LEVEL			AT SEA LEVEL			AT SEA LEVEL						
	HEAD WIND MPH, KTS	GROUND TO CLEAR 50 FT. 50' OH'L.	TIME TO CLEAR 50 FT. 50' OH'L.	GROUND TO CLEAR 50 FT. 50' OH'L.	TIME TO CLEAR 50 FT. 50' OH'L.	GROUND TO CLEAR 50 FT. 50' OH'L.	TIME TO CLEAR 50 FT. 50' OH'L.	GROUND TO CLEAR 50 FT. 50' OH'L.	TIME TO CLEAR 50 FT. 50' OH'L.				
28,000	0	1,030	27.00	1,180	29.75	1,850	36.75	1,670	32.50	2,510	42.25	2,118	35.60
	6	1,020	27.00	1,180	29.75	1,850	36.75	1,670	32.50	2,510	42.25	2,118	35.60
	12	920	27.40	1,040	29.75	1,650	36.75	1,470	32.50	2,118	35.60	1,610	29.05
	18	850	28.00	960	30.25	1,450	37.25	1,270	33.00	1,818	36.10	1,310	29.55
	24	800	28.40	910	30.75	1,300	37.75	1,120	33.50	1,668	36.60	1,160	29.60
	30	760	28.80	860	31.25	1,150	38.25	970	34.00	1,518	37.10	1,010	29.65
31,000	0	1,040	27.50	1,200	30.25	1,870	38.00	1,700	33.75	2,530	42.75	2,130	35.85
	6	1,030	27.50	1,200	30.25	1,870	38.00	1,700	33.75	2,530	42.75	2,130	35.85
	12	940	27.90	1,060	30.75	1,670	38.50	1,500	34.25	2,140	37.25	1,620	30.10
	18	870	28.50	980	31.25	1,470	39.00	1,300	34.75	1,910	37.75	1,420	30.15
	24	820	28.90	930	31.75	1,320	39.50	1,150	35.25	1,760	38.25	1,270	30.20
	30	780	29.30	880	32.25	1,170	40.00	1,000	35.75	1,610	38.75	1,120	30.25
34,000	0	1,060	28.00	1,230	30.75	1,910	38.50	1,740	34.25	2,560	43.25	2,160	36.10
	6	1,050	28.00	1,230	30.75	1,910	38.50	1,740	34.25	2,560	43.25	2,160	36.10
	12	970	28.40	1,090	31.25	1,710	39.00	1,540	34.75	2,170	38.75	1,640	30.35
	18	900	29.00	1,010	31.75	1,510	39.50	1,340	35.25	1,920	39.25	1,440	30.40
	24	850	29.40	960	32.25	1,360	40.00	1,190	35.75	1,770	39.75	1,290	30.45
	30	810	29.80	910	32.75	1,210	40.50	1,040	36.25	1,620	40.25	1,140	30.50

NOTE: INCREASE CHART DISTANCES AS FOLLOWS: 15% X 30K; 10% X 20K; 5% X 15K; 10% X 10K; 15% X 5K; 20% X 0. 1.00 X 0. 2.00 X 0. 3.00 X 0. 4.00 X 0. 5.00 X 0. 6.00 X 0. 7.00 X 0. 8.00 X 0. 9.00 X 0. 10.00 X 0. 11.00 X 0. 12.00 X 0. 13.00 X 0. 14.00 X 0. 15.00 X 0. 16.00 X 0. 17.00 X 0. 18.00 X 0. 19.00 X 0. 20.00 X 0. 21.00 X 0. 22.00 X 0. 23.00 X 0. 24.00 X 0. 25.00 X 0. 26.00 X 0. 27.00 X 0. 28.00 X 0. 29.00 X 0. 30.00 X 0. 31.00 X 0. 32.00 X 0. 33.00 X 0. 34.00 X 0. 35.00 X 0. 36.00 X 0. 37.00 X 0. 38.00 X 0. 39.00 X 0. 40.00 X 0. 41.00 X 0. 42.00 X 0. 43.00 X 0. 44.00 X 0. 45.00 X 0. 46.00 X 0. 47.00 X 0. 48.00 X 0. 49.00 X 0. 50.00 X 0. 51.00 X 0. 52.00 X 0. 53.00 X 0. 54.00 X 0. 55.00 X 0. 56.00 X 0. 57.00 X 0. 58.00 X 0. 59.00 X 0. 60.00 X 0. 61.00 X 0. 62.00 X 0. 63.00 X 0. 64.00 X 0. 65.00 X 0. 66.00 X 0. 67.00 X 0. 68.00 X 0. 69.00 X 0. 70.00 X 0. 71.00 X 0. 72.00 X 0. 73.00 X 0. 74.00 X 0. 75.00 X 0. 76.00 X 0. 77.00 X 0. 78.00 X 0. 79.00 X 0. 80.00 X 0. 81.00 X 0. 82.00 X 0. 83.00 X 0. 84.00 X 0. 85.00 X 0. 86.00 X 0. 87.00 X 0. 88.00 X 0. 89.00 X 0. 90.00 X 0. 91.00 X 0. 92.00 X 0. 93.00 X 0. 94.00 X 0. 95.00 X 0. 96.00 X 0. 97.00 X 0. 98.00 X 0. 99.00 X 0. 100.00 X 0.

CLIMB DATA

GROSS WEIGHT L.B.	AT 5,000 FEET			AT 10,000 FEET			AT 15,000 FEET			AT 20,000 FEET			AT 25,000 FEET						
	BEST I.A.S.			BEST I.A.S.			BEST I.A.S.			BEST I.A.S.			BEST I.A.S.						
	MPH	KTS	CLIMB FT./MIN. USED	MPH	KTS	CLIMB FT./MIN. USED	MPH	KTS	CLIMB FT./MIN. USED	MPH	KTS	CLIMB FT./MIN. USED	MPH	KTS	CLIMB FT./MIN. USED				
28,000	89	77	890	50	89	77	880	42.2	100	89	77	425	21.2	130	89	77	170	37.8	105
31,000	93	81	790	50	93	81	690	7.25	80	58	61	530	14.3	110	58	61	280	27.3	155
34,000	98	85	610	50	98	85	560	6.5	85	65	85	400	18.5	120	98	85	150	38.7	190

FUEL PLANT SETTING: 10.0 GAL. ON FIG. SECTION 11111. FUEL USED (U.S.GAL.) INCLUDES WAKE-UP & TAKE-OFF ALLOWANCE.

LANDING DISTANCE FEET

GROSS WEIGHT L.B.	HARD DRY SURFACE			FIRM DRY SOID			MET OR SLIPPERY														
	AT SEA LEVEL			AT SEA LEVEL			AT SEA LEVEL														
	POWER OFF	FLYER ON	TIME TO CLEAR 50 FT. 50' OH'L.	POWER OFF	FLYER ON	TIME TO CLEAR 50 FT. 50' OH'L.	POWER OFF	FLYER ON	TIME TO CLEAR 50 FT. 50' OH'L.												
28,000	85	72	67	980	25.0	1050	24.0	1170	25.8	1190	24.4	1230	25.9	1170	27.8	3900	51.8	4260	56.0	4680	60.0
31,000	89	82	74	900	26.0	1070	25.0	1200	26.8	1220	26.0	1260	27.0	1200	30.0	4300	54.8	4580	61.0	5000	66.0
34,000	95	88	78	820	27.0	1000	26.0	1150	27.8	1180	27.0	1220	28.0	1120	31.0	4100	58.8	4380	64.0	5480	71.8

DATA AS OF OCT. 1948. 1. I.A.S. : INDICATED AIRSPEED
2. M.P.H. : MILES PER HOUR
3. K.T.S. : KNOTS
4. FEET : FEET PER MINUTE

REMARKS:
BASED ON CALCULATIONS
MULTIPLY BY 10, THEN DIVIDE BY 12

Figure 62—Take-off, Climb and Landing Chart

RESTRICTED
AN 01-SMC-1

Appendix I

AIRCRAFT MODEL(S) PBY-6A		FLIGHT OPERATION INSTRUCTION CHART				EXTERNAL LOAD ITEMS NONE			
ENGINE(S): R-1830-92		CHART WEIGHT LIMITS: 32,000 TO 34,000 POUNDS				NUMBER OF ENGINES OPERATING: 2			
LIMITS W.P. BEHIND PROPELLER TUBE C.V.L. TOTAL INCHES POSITION POSITION INCHES INCHES WAR EMERGENCY MILITARY POWER		INSTRUCTIONS FOR USING CHART: SELECT FIGURE IN FUEL COLUMN EQUAL TO OR LESS THAN AMOUNT OF FUEL TO BE USED FOR CRUISING (SEE NOTE 4). MOVE CURSOR TO RIGHT OF LEFT AND SELECT RANGE VALUE WHICH CORRESPONDS TO RANGE. MOVE CURSOR TO RIGHT OF RIGHT AND SELECT RANGE VALUE TO BE FLOWN, VERTICALLY BELOW AND OPPOSITE VALUE READ LEFT DESIRED CRUISING ALTITUDE (ALT., READ RPM, MANIFOLD PRESSURE (M.P.), AND MIXTURE SETTING REQUIRED.		NOTES: COLUMN I IS FOR EMERGENCY HIGH SPEED CRUISING (SLOWING TO 1141 RPM AND VIVE PROGRESSIVE INCREASE IN RANGE AT A SPECIFIC ALTITUDE). COLUMN II IS FOR CRUISING AT 1200 RPM. COLUMN III IS FOR CRUISING AT 1000 RPM. COLUMN IV IS FOR CRUISING AT 800 RPM. COLUMN V IS FOR CRUISING AT 600 RPM. RANGE VALUES ARE FOR AN AVERAGE AIRPLANE (WITH NO WIND) TO COUNTER BALANCE IMPERIAL GALL (OR U.S. LIQUID GALLON) OF EXTERNAL LOADS. (SEE NOTE 2)		NONE			
COLUMN I		COLUMN II		COLUMN III		COLUMN IV		COLUMN V	
FUEL	U.S. GAL.	RANGE IN AIRMILES	STATUTE NAUTICAL	RANGE IN AIRMILES	STATUTE NAUTICAL	RANGE IN AIRMILES	STATUTE NAUTICAL	RANGE IN AIRMILES	STATUTE NAUTICAL
94.5	820	1255	1090	1380	1200	1545	1340	1965	1710
710	615	940	815	1035	900	1160	1005	1465	1275
470	410	625	545	690	600	770	670	980	855
235	205	310	270	345	300	385	335	480	420

MAXIMUM CONTINUOUS		PRESS		M.P. BEHIND PROPELLER TUBE		M.P. BEHIND PROPELLER TUBE		M.P. BEHIND PROPELLER TUBE		M.P. BEHIND PROPELLER TUBE	
W.P. INCHES	T.C.A.S. FEET	(.9) STAT. (1.0) NAUT. (1.0) STAT. (1.0) NAUT. (1.2) STAT. (1.0) NAUT.	R.P.M. INCHES	T.C.A.S. FEET	R.P.M. INCHES	T.C.A.S. FEET	R.P.M. INCHES	T.C.A.S. FEET	R.P.M. INCHES	T.C.A.S. FEET	R.P.M. INCHES
4000	5000	35000	30000	35000	30000	35000	30000	35000	30000	35000	30000
5000	6000	25000	20000	25000	20000	25000	20000	25000	20000	25000	20000
6000	7000	10000	8000	10000	8000	10000	8000	10000	8000	10000	8000
7000	8000	1500	1200	1500	1200	1500	1200	1500	1200	1500	1200
8000	9000	2000	1600	2000	1600	2000	1600	2000	1600	2000	1600
9000	10000	2500	2000	2500	2000	2500	2000	2500	2000	2500	2000
10000	11000	3000	2400	3000	2400	3000	2400	3000	2400	3000	2400
11000	12000	3500	2800	3500	2800	3500	2800	3500	2800	3500	2800
12000	13000	4000	3200	4000	3200	4000	3200	4000	3200	4000	3200
13000	14000	4500	3600	4500	3600	4500	3600	4500	3600	4500	3600
14000	15000	5000	4000	5000	4000	5000	4000	5000	4000	5000	4000
15000	16000	5500	4400	5500	4400	5500	4400	5500	4400	5500	4400

SPECIAL NOTES		EXAMPLE		LEGEND	
(1) W.P. ALLOWANCE FOR WIND, PITCH, ALTITUDE & CLIMB (SEE FIG. 2)	(2) W.P. ALLOWANCE FOR WIND, PITCH, ALTITUDE & CLIMB AS REQUIRED.	43,000 LBS. EXCESS WEIGHT WITH 640 GAL. OF FUEL	10000	1000	P.R. - FULL RPM
		TO FLY 600 STAT. AIRMILES AT 5000 FT. ALTITUDE	8000	5000	A.P. - APPROXIMATE ALTITUDE
		WITH MIXTURE SET ALL.	11778 RPM MANIFOLD PRESSURE	1725	T.C.S. - TURBOCHARGER SPEED
				2000	A.L.T. - CRUISING ALTITUDE
				114	C.L. - CRUISING LEAN
				114	M.L. - MANIFOLD LEAN
				114	K.T.S. - KNOTS
				114	M.P. - FULL PROPELLER
				114	S.L. - SEA LEVEL

DATA AS OF 4 OCT. 1944 BASED ON DOC. 28-1-2A

SEE FIGURES ARE PRELIMINARY DATA. SUBJECT TO REVISION AFTER FLIGHT CHECK

Figure 63—Flight Operation Instruction Chart

CRUISING CHART

MIN. SPEC. CONSUMPTION
140 BMEP—Auto Lean

"INTERMEDIATE" CRUISE
140 BMEP—Auto Lean

MAXIMUM CRUISE
140 BMEP—Auto Lean

Pressure Altitude	MAXIMUM CRUISE 140 BMEP—Auto Lean		"INTERMEDIATE" CRUISE 140 BMEP—Auto Lean		MIN. SPEC. CONSUMPTION 140 BMEP—Auto Lean	
	RPM	Man. Pres. °Hg (Abs)	RPM	Man. Pres. °Hg (Abs)	RPM	Man. Pres. °Hg (Abs)
1,000	2170	33.5	1950	33.5	1610	33.0
4,000	2170	32.0	1950	32.0	1610	32.0
7,000	2170	31.0	1950	31.0	1650	F.T.*
10,000	2170	30.5	2050**	F.T.*	**	**
13,000	2275**	F.T.*	**	**	**	**

* Full throttle altitude varies with operating conditions.

** Increase RPM to maintain power (140BMEP no longer obtainable).

Figure 64—Cruising Chart

RESTRICTED
AN 01-SMC-1

Appendix I




Figure 65—Cruising Control Chart

RESTRICTED

RESTRICTED
AN 01-5MC-1




Figure 66—Engine Operating Limits Curve